

RACKMUX® Series

RACKMUX-DS17-N-4/8/16DVIHD DVI USB SUN KVM Drawer with USB KVM Switch and DVI Video Support Installation and Operation Manual



TRADEMARK

RACKMUX is a registered trademark of Network Technologies Inc in the U.S. and other countries.

COPYRIGHT

Copyright © 2008-2018 by Network Technologies Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Network Technologies Inc, 1275 Danner Drive, Aurora, Ohio 44202.

CHANGES

The material in this guide is for information only and is subject to change without notice. Network Technologies Inc reserves the right to make changes in the product design without reservation and without notification to its users.

TABLE OF CONTENTS

| | |
|---|----|
| INTRODUCTION..... | 1 |
| Models Available..... | 1 |
| Types of CPUs Supported..... | 1 |
| Features..... | 1 |
| Option..... | 1 |
| MATERIALS..... | 2 |
| FEATURES AND FUNCTIONS..... | 3 |
| INSTALLATION..... | 4 |
| Rack Mounting Instructions..... | 4 |
| Extension Bracket Method..... | 4 |
| One-Man Installation Method..... | 5 |
| Optional Telco 2-Post Mounting..... | 8 |
| Connect The Cables..... | 9 |
| RS232 Connection..... | 10 |
| Power-Up Sequence..... | 10 |
| USING THE UNIMUX..... | 11 |
| Front Panel Control..... | 11 |
| Keyboard Control..... | 11 |
| Command Mode..... | 11 |
| Scan Mode..... | 12 |
| Broadcast Mode..... | 12 |
| Normal Mode..... | 12 |
| No Sun Sleep Mode..... | 13 |
| Select Country\Language Code..... | 13 |
| RS232 CONTROL..... | 14 |
| RS232 Connections and Configuration..... | 14 |
| Remote Connection..... | 14 |
| Baud Rate..... | 14 |
| Unit Address and Loop Back..... | 15 |
| Command Protocol..... | 16 |
| NTI Switch Control Program For Windows 9X, NT, 2000, XP, And Vista..... | 18 |
| SerTest- RS232 Interface Test Program..... | 18 |
| Main Options..... | 18 |
| DISPLAY FUNCTIONS..... | 20 |
| Standard Controls..... | 20 |
| OSD Control Menu..... | 21 |
| OSD Main Menu..... | 21 |
| Brightness/Contrast Menu..... | 21 |
| Setup Menu..... | 22 |
| KEYBOARDS..... | 23 |
| Keyboard Configuration..... | 23 |
| TROUBLESHOOTING..... | 24 |
| RACKMUX SPECIFICATIONS..... | 25 |
| General Specs..... | 25 |
| LCD – 17”..... | 25 |
| Display Controller: DVI..... | 25 |
| OSD Control Board..... | 25 |
| Keyboard..... | 25 |
| Trackball..... | 26 |
| Touchpad..... | 26 |
| INDEX..... | 26 |
| WARRANTY INFORMATION..... | 26 |

TABLE OF FIGURES

| | |
|---|----|
| Figure 1- Mount RACKMUX to a standard rack..... | 4 |
| Figure 2- Adjustable rail depth..... | 5 |
| Figure 3- Install cage nuts..... | 5 |
| Figure 4- Install rail assemblies..... | 6 |
| Figure 5- Adjust distance between rails..... | 6 |
| Figure 6- Slide the RACKMUX into the rails..... | 7 |
| Figure 7- Secure the RACKMUX..... | 7 |
| Figure 8- Position RACKMUX with clearance to open..... | 8 |
| Figure 9- Mount to Telco post with optional mounting brackets..... | 8 |
| Figure 3- Connect each CPU..... | 9 |
| Figure 4- Connect the power cord..... | 9 |
| Figure 5- Connect RS232 control terminal..... | 10 |
| Figure 6- CPU Select switches, status LEDs and Mode LEDs..... | 11 |
| Figure 7- Country\Language Codes for international SUN keyboards..... | 13 |
| Figure 8- RS232 DIP switches..... | 14 |
| Figure 9- RS232 connection with Matrix-Y-1 cable..... | 15 |
| Figure 10- Pinout of Matrix-Y-1 cable..... | 16 |
| Figure 11- RS232 Communication Illustrated..... | 16 |
| Figure 12- OSD Controls..... | 20 |
| Figure 13- U.S. (English) SUN Keyboard with numeric keypad..... | 23 |
| Figure 14- French SUN Keyboard with numeric keypad..... | 23 |

INTRODUCTION

The RACKMUX-DS17-N(T)-xDVIHD is a KVM Drawer with USB KVM Switch (**RACKMUX**) that combines a rackmount 17" TFT/LCD DVI monitor, SUN keyboard, trackball or touch pad mouse, and USB KVM switch (**UNIMUX**) in a space-saving 1RU industrial strength drawer. The RACKMUX is equipped with a built-in switch function, which allows control of up to sixteen DVI-enabled USB computers with a single SUN keyboard, trackball or touchpad and DVI monitor. When access to a server rack is needed, the drawer can be pulled out and the display lifted up like a notebook computer, revealing the SUN keyboard and trackball or touchpad. When the drawer is not in use, the display can be folded forward and down so the 1RU drawer can be pushed into the cabinet easily and smoothly, helping to organize and streamline busy server rooms.

The onboard USB KVM switch allows access to any DVI-enabled Windows, MAC, or SUN USB CPUs from one DVI monitor, USB keyboard and USB mouse (up to 16 CPUs). Internal microprocessor circuitry allows all USB CPUs to be booted simultaneously without keyboard error. Port selection is accomplished through switches on the keyboard tray or keyboard commands.

Models Available

- RACKMUX-DS17-NT-4DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor, trackball mouse and 4-port UNIMUX
- RACKMUX-DS17-N-4DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor, touchpad mouse and 4-port UNIMUX
- RACKMUX-DS17-NT-8DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor trackball mouse and 8-port UNIMUX
- RACKMUX-DS17-N-8DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor, touchpad mouse and 8-port UNIMUX
- RACKMUX-DS17-NT-16DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor, trackball mouse and 16-port UNIMUX
- RACKMUX-DS17-N-16DVIHD - KVM Drawer with 17" TFT/LCD DVI monitor, touchpad mouse and 16-port UNIMUX

Types of CPUs Supported

Any DVI-enabled USB CPU supporting USB version 1.0 or above including:

- USB WINxx
- USB MAC
- USB SUN

Features

- Entire unit is only 1RU (1.75") high
- High-quality metal construction (ideal for most industrial and commercial settings)
- 17" Rack Mount LCD Monitor features a wide viewing angle
- 1280x1024 resolution
- A forward-folding 17" TFT LCD DVI monitor
- Includes rack mount kit suitable for SUN and most EIA 19" racks
- Fits varying rack depths from 22" to 39" deep via adjustable mounting brackets
- DVI Video Compatible
- Powered by 110 or 220VAC, 50 or 60Hz with country-specific line cord
- Auto shut-OFF switch: Turns OFF the power to the monitor when the LCD is in a folded-closed position
- Standard 3-button touchpad
- Added security with a drawer lock to prevent unwanted access
- Locking rails to prevent movement of the drawer when fully extended
- Multi-language support including: US(English), UK(English), German, French, Italian, and Spanish

Option

- Rackmounting kit for two-post Telco rack - order RL-T15-TEL

MATERIALS

Materials supplied with this kit:

- NTI RACKMUX-DS17-N(T)-xDVIHD KVM Drawer with USB KVM Switch (where x= 4,8 or 16)
- Line cord, country specific
- Set of keys for keylock
- 2 Rear Mounting Brackets w/ 4 nuts
- 8pcs #10-32x3/4" screws and cage nuts for mounting to a rack
- URL slip with address to pdf of this manual
- 1- DB9 Female-to-RJ45 Female adapter
- 1- 5 foot RJ45-to-RJ45 CAT5 patch cable

Materials *Not* supplied but **REQUIRED**:


- USB-DHEXT-xx-MM cable for each CPU being connected to the switch- for DVI monitor, USB keyboard, and USB mouse support- available in 3, 6,10, and 15 foot lengths


where:

xx is the length of the cable in feet

MM indicates male-to-male connector

Cables can be purchased from Network Technologies Inc by calling **(800) 742-8324** (800-RGB-TECH) in the US and Canada or **(330) 562-7070** (worldwide).





FEATURES AND FUNCTIONS

1. **Power Button**- press to turn the LCD monitor ON and OFF
2. **Power LED**- Indicates operation status
Green = Power-ON, Video Input Signal OK
Red = Suspend / Stand-by, or no Video Input Signal
3. **Menu Button**- press to turn ON the OSD menu
4. **Up Arrow Button**- press to move the cursor in the OSD menu up
5. **Down Arrow Button**- press to move the cursor in the OSD menu down
6. **Select Button**- press to select a menu item (when OSD menu is ON) or press to auto adjust the video quality (when OSD menu is OFF)
7. **NumLock LED**- illuminates when the Num Lock is ON
8. **CapsLock LED**- illuminates when Caps Lock is ON
9. **Scroll Lock LED**- illuminates when the Scroll Lock keyboard feature is ON
10. **Compose LED**- illuminates when the Compose keyboard feature is ON
11. **Keylock**- to prevent unauthorized use of the RACKMUX
12. **3-button Touch Pad or Trackball**- for controlling mouse movements on the monitor and controlling the computer
13. **Keyboard**- for manual data entry and computer control
14. **Auto Shut-OFF**- switch automatically shuts OFF the LCD display when the monitor is folded down
15. **LCD Display**- for viewing the video signal from the connected CPU
16. **CPU Select Switch**- push to manually switch to a specific CPU or change the switch operating mode
17. **CPU Status LED**- for visual indication of connection between the user and a specific CPU
18. **Mode Status LEDs**- for visual indication of switch operating mode
19. **IEC Connector w/Built-in 2A 240VAC Replaceable Fuse**- for attachment of the AC power cord to power the RACKMUX drawer
20. **Power Switch**- to power the RACKMUX ON/OFF
21. **RS232**- RJ45 connector- for attachment of an RS232 control cable
22. **CPU x**- HDMI Type A female connectors- for connecting USB-DHEXT-xx-MM cables from CPUs
23. **RS232 DIP Switches**- for controlling the baud rate of the RACKMUX for RS232 communication
24. **DDC**- recessed button used to reset DDC information between the RACKMUX and the connected CPU

INSTALLATION

Rack Mounting Instructions

The RACKMUX was designed to be mounted to a rack and includes mounting flanges to make attachment easy. The rails that are provided for rack mounting will either be empty studs for insertion through slots in a rear extension bracket, or rail guides for one-man installation to a front and rear bracket set. Depending upon the method provided, install your RACKMUX according to the instructions below.



Stud for mount to extension bracket



Guide for one-man installation method

Extension Bracket Method

1. Determine the mounting height in the rack for the drawer. It should be a height comfortable to use the keyboard and see the LCD display. Mark holes in each of the 4 corner cabinet rails at points all level with each other.
2. Secure the rear brackets to the rear rack cabinet rails. Apply the top screws (supplied) for each bracket to the holes marked in step 1.
3. Lift the keyboard into position and line the studs on the left and right sides up with the slotted openings in the rear bracket. Apply the nuts (supplied) to the studs but do not tighten the nuts yet.

FYI: There are 4 mounting studs provided on each side of the RACKMUX. Depending on the depth of the rack and distance apart of the cabinet rails, the position of the rear bracket may make all 4 studs available for use. In this case, apply the 2 nuts to the studs furthest apart from each other on each side.

4. Slide the drawer in until the top holes in the front bracket flanges line up with the holes marked in step 1. Secure the front brackets on the drawer to the front cabinet rails with two screws per bracket. Be sure to tighten the screws securely. Then tighten the nuts applied in step 3.
5. Apply one more screw to each of the rear brackets to finish.




Figure 1- Mount RACKMUX to a standard rack

One-Man Installation Method

If you would like to see a video of this installation, see the [“single-person-installation”](#) video .

1. Locate and unpack the hardware bag. Your hardware bag will include all items necessary to install the specific RACKMUX model (see the manual that accompanied your RACKMUX drawer), including the following hardware unique to the Single-Person hardware installation:

- 10- #10-32 cage nut
- 2- #10-32 x 1/2" flat-head machine screw
- 8- #10-32 x 3/4" pan-head machine screw



To install the rails you will need only a tape measure and Phillips screwdriver.

2. Unpack the left and right rail assemblies. Each are labeled “Right Front” and “Left Front” to indicate their intended position and orientation. Extend each rail assembly to the dimension required for your rack. Rail assemblies are adjustable to fit within a rack between 24” and 40” in depth.




Figure 2- Adjustable rail depth

3. Install six #10-32 cage nuts at the front of the rack in positions where the RACKMUX will be mounted (three in each side). Install four more cage nuts at the rear of the rack in positions straight across from the upper and lower cage nuts installed in front.




Figure 3- Install cage nuts

4. Install the right rail assembly. The end with the label "Right Front" mounts to the front rack support. Install only the center screw through the rail flange to the rack support and cage nut using the #10-32 x 1/2" flat head machine screw provided. (See image below.) Do not tighten at this time. Install the left rail assembly in the same fashion. The end with the label "Left Front" mounts to the front rack support.
5. Install two #10-32 x 3/4" pan-head screws in the rear of each rail assembly as shown below. Do not tighten at the time.




Figure 4- Install rail assemblies

6. Measure the distance between the inside of the rails at the front of the rack. Adjust the distance to 17-1/4" and tighten the flat-head screws to the rail flanges securely.




Figure 5- Adjust distance between rails

7. Lineup the rail guides on the RACKMUX drawer with the slots in the front of the left and right rails and slide the drawer into the rack. The rail guides should be positioned such that the wide lip of the guide is on the backside of the rail. Slide the drawer in completely.




Figure 6- Slide the RACKMUX into the rails

8. Apply four more #10-32 x 3/4" pan-head machine screws (two for each) through the holes in the drawer flanges, through the holes in the left and right rails, into the cage nuts in the rack supports. Tighten each securely.




Figure 7- Secure the RACKMUX

9. Tighten securely the four screws applied to the rear rail flanges in step 4.

Note: To provide sufficient room for the LCD monitor to be opened to a proper viewing angle (a minimum 90 degree position from the keyboard), ensure that all devices mounted above the RACKMUX extend no more than 1.75" from the rack frame. (See Figure 8)





Figure 8- Position RACKMUX with clearance to open

Optional Telco 2-Post Mounting

If the Telco 2-post mounting bracket kit (NTI# RL-T15-TEL) is to be used, secure the short and long brackets to each side of the drawer as shown in Figure 9. Apply 2 nuts (supplied) per bracket to secure the brackets to the drawer. Apply two #10-32x3/4" screws (supplied) per bracket to the post at the desired height. Slots are provided in the brackets to make minor depth adjustments easy. Be sure to properly tighten all nuts and screws before using the drawer.



View of right side of drawer with optional Telco mounting brackets

Figure 9- Mount to Telco post with optional mounting brackets

Connect The Cables

FYI: It is not necessary to turn the CPUs or monitors OFF during this installation.

1. Connect each CPU to the UNIMUX switch using a USB-DHEXT-xx-MM (Required-not supplied) as shown in Figure 10.




Figure 10- Connect each CPU

2. Connect the power cord to the IEC power connector.




Figure 11- Connect the power cord

RS232 Connection

If RS232 control will be used, connect one end of the CAT5 patch cable (supplied) to the port labeled “RS232” on the rear of the RACKMUX. Plug the other end of the CAT5 cable into the RJ45-to-DB9 adapter supplied and connect the adapter to the RS232 port on the control terminal. Follow the instruction under “RS232 Control” on page 14 for configuration and use of the RS232 control feature.




Figure 12- Connect RS232 control terminal

Power-Up Sequence

1. Using the key, unlock the drawer and slide the keyboard and LCD Display out far enough to raise the display to a comfortable viewing angle.
2. Power ON the RACKMUX with the power switch located on the rear of the drawer.
3. Power ON the monitor with the power switch located on the monitor.
4. Adjust the screen's brightness and contrast with the controls also located on the monitor— as needed.
5. Power ON any attached CPUs.

FYI: The CPUs can be powered at any time, although if a CPU needs a keyboard and/or mouse at power-ON, it should be powered after connecting to and powering-ON the RACKMUX.

USING THE UNIMUX

Once the RACKMUX is properly connected, the UNIMUX switch will enable a connection to be made between the attached CPUs and the monitor, keyboard, and mouse.

The UNIMUX can be controlled by three methods:

- front panel control using touch-switches and LEDs on the keyboard tray
- keyboard control through Command Mode
- RS232 control (see page 14)

Front Panel Control

There is a panel of numbered touch-switches and LEDs on the keyboard tray of the RACKMUX. There is one switch and LED for each CPU the switch will connect the monitor and input devices to. Pressing any touch-switch will connect the corresponding CPU to the monitor and input devices.

Holding down any touch-switch for more than 2 seconds will cause the UNIMUX to cycle through all modes of operation including COMMAND, BROADCAST, SCAN, and NORMAL (described in "Command Mode" below). The three MODE LEDs on the panel indicate which mode is selected. Release the touch-switch when the LEDs indicate the desired mode. When no mode LEDs are illuminated the user is in Normal Mode controlling directly the CPU to which the user is connected through the UNIMUX.




Figure 13- CPU Select switches, status LEDs and Mode LEDs

Keyboard Control

Keyboard control of the UNIMUX switch is achieved using Command Mode - operated using the keyboard. By pressing <Ctrl> + <~> (accent/tilde key), the user can enter Command Mode. Once in Command Mode, typing a series of commands will cause the UNIMUX switch to connect the user to any one CPU connected to the switch. Pressing the <Esc> key will exit Command Mode. The following instruction describes how to use the menus to operate the UNIMUX switch.

Command Mode

In order to control the UNIMUX with the keyboard connected, Command Mode must be enabled. To enter Command Mode from the keyboard:



When the COMMAND LED is illuminated, all 3 LEDs on the keyboard will illuminate (caps lock, scroll lock, and num lock) to indicate that Command Mode is enabled and the following functions are available:

Basic Command Functions

Function:

Keystroke:

Increment Port



Decrement Port



| KEY SYMBOLS LEGEND: | |
|---------------------|--|
| OR | PRESS EITHER KEY |
| + | CHORDED SEQUENCE- PRESS CONSECUTIVELY AND KEEP KEYS PRESSED UNTIL ALL ARE PRESSED. |
| - | PRESS CONSECUTIVELY |

| | | |
|---|--|---|
| Toggle Scan Mode ON and OFF |  | (The SCAN Mode LED will also toggle ON and OFF) |
| Toggle Broadcast Mode ON and OFF |  | (The Broadcast Mode LED will toggle ON and OFF.) |
| Sets scan time-out period for each port. |  -  -  -  | (xxx from 002 to 255. ie. T002 would set the time-out period for 2 seconds) |
| Selects a specific port |  -  -  | (Pxx would be P01, P02, etc.) |
| Configure port to connect To a MAC CPU |  +  +  | (xx= 01-8 <M> + <0> + <1> will enable function on Port 1 <M> + <0> + <4> will enable function on Port 4. Keyboard LED's will flash once to confirm command.) |
| Configure port to connect To a WINDOWS or SUN CPU |  +  +  | (xx= 01-8 <W> + <0> + <1> will disable function on Port 1 <W> + <0> + <4> will disable function on Port 4. Keyboard LED's will flash once to confirm command.) |
| Exit Command Mode |  | <div style="border: 1px solid black; padding: 5px;"> <p>FYI: The user must exit Command Mode to type to a CPU.</p> <p>To exit Command Mode, either hold down any touch-switch on the front panel for more than 2 seconds, OR press <ESC> on the keyboard.</p> </div> |

Scan Mode

To activate Scan Mode press <s> while in Command Mode menu. When in Scan Mode the switch scans to each port with a CPU powered-ON. (The SCAN LED on the front panel will illuminate and remain ON while in Scan Mode.) The port with the CPU powered-ON remains active while in use until it becomes idle for the configured dwell time (default time-out period is 5 seconds) before switching to the next powered-ON CPU port. See Command Mode section above for configuring the scan dwell time.

Note: The keyboard and mouse must remain idle for the full scan dwell time before the switch selects the next active port.

To begin scanning, press <Esc> to exit Command Mode.

To deactivate Scan Mode press <s> again while in Command Mode.

Broadcast Mode

To activate Broadcast Mode press while in Command Mode. Broadcast Mode enables the user to type characters to all powered-ON CPUs simultaneously.

Note: The user must type somewhat slowly (less than 20 wpm) when in Broadcast Mode and cannot use the <Backspace> key.

To begin broadcasting, press <Esc> to exit Command Mode.

To deactivate Broadcast Mode press again while in Command Mode.

Normal Mode

When the Broadcast, Scan, and Command LEDs are all OFF the user is in Normal Mode, controlling the CPU to which the user is connected through the UNIMUX.

No Sun Sleep Mode

Note: It is necessary to configure a Sun CPU (most versions) such that the Sleep Mode is not enabled. If the Sun CPU goes into Sleep Mode either automatically or manually, the user must reboot the Sun CPU in order to resume use of the Sun CPU.

To disable the Sleep Mode, perform the following steps:

1. Select "Power Manager"
2. Look for "Device Idle Time Before Power Saving Starts"
3. Select "Always ON"
4. Look for "Override Device Idle Time For:"
5. Make sure neither "Monitors" nor "Disks" are selected.

Select Country\Language Code

It is possible to configure the UNIMUX to emulate a specific international Sun keyboard regardless of what actual keyboard is connected. This is recommended when the CPU needs the layout code (i.e. a SUN CPU) and the keyboard doesn't have an explicit layout code (i.e. some Windows keyboards). To do this, manually set the UNIMUX to indicate the international keyboard identification number to the CPU using the following procedure;

1. Enter Command Mode
2. Type Lxx, where xx is the number from the list below that corresponds to the desired country code
3. Exit Command Mode

Note: If any SUN CPUs are connected to the UNIMUX, they must be rebooted. Keyboard configuration is only read by SUN CPUs on startup.

| Country\Language Codes | | | | | |
|------------------------|--------------------|----|---------------------|----|--------------|
| 00 | Auto Detect | 13 | International (ISO) | 26 | Swedish |
| 01 | Arabic | 14 | Italian | 27 | Swiss/French |
| 02 | Belgian | 15 | Japan (Katakana) | 28 | Swiss/German |
| 03 | Canadian-Bilingual | 16 | Korean | 29 | Switzerland |
| 04 | Canadian-French | 17 | Latin American | 30 | Taiwan |
| 05 | Czech Republic | 18 | Netherlands/Dutch | 31 | Turkish |
| 06 | Danish | 19 | Norwegian | 32 | UK |
| 07 | Finnish | 20 | Persian (Farsi) | 33 | US |
| 08 | French | 21 | Poland | 34 | Yugoslavia |
| 09 | German | 22 | Portuguese | | |
| 10 | Greek | 23 | Russia | | |
| 11 | Hebrew | 24 | Slovakia | | |
| 12 | Hungary | 25 | Spanish | | |

Figure 14- Country\Language Codes for international SUN keyboards

RS232 CONTROL

RS232 enables the UNIMUX to be remotely controlled via RS232. To control the UNIMUX via RS232 the user has three options:

- write a program that runs on a PC using the Command Protocol (page 16)
- use the NTI Switch Control Program (page 18)
- use the SerTest program (page 18)
-

RS232 Connections and Configuration

Remote Connection

The RS232 Interface is designed to meet the RS232C standard and can be controlled from any CPU or other controller with an RS232 communications port. The pin-out for the RJ45 connector on the unit is as follows:

RS232 (RJ45) CONNECTOR

| PIN | SIGNAL | FUNCTION |
|-----|--------|-----------------------------|
| 1 | - | No connection |
| 2 | - | No connection |
| 3 | RX+ | Receive data (TXD at host) |
| 4 | GND | Ground |
| 5 | - | No connection |
| 6 | TX+ | Transmit data (RXD at host) |
| 7 | - | No connection |
| 8 | - | No connection |

A 5 foot patch cable and RJ45-to-DB9 adapter have been provided for connection to most CPUs (see page 10).

Baud Rate

The baud rate can be changed by powering down the unit, changing the 8-position RS232 DIP switch on the rear of the UNIMUX, and then powering back up. This table shows how to set the baud rate. (Figure 15 shows switches in their factory-default position.)

| DIP SWITCH | | BAUD RATE |
|------------|-----|----------------|
| 3 | 2 | |
| OFF | OFF | 2400 |
| OFF | ON | 9600 (default) |
| ON | OFF | 19200 |
| ON | ON | 38400 |




Figure 15- RS232 DIP switches

Unit Address and Loop Back

To allow multiple units to be controlled from a single CPU serial port, the RS232 control interface is designed to allow "daisy chaining" up to 7 units. By setting the appropriate RS232 DIP switches, each unit can be given a unique address (1-7). Then the unit will only respond to commands on the bus if its address is embedded in the command. Use the following table to set the unit address.

| DIP SWITCH | | | | UNIT ADDRESS |
|------------|-----|-----|-----|---------------|
| 8 | 7 | 6 | 5 | |
| OFF | OFF | OFF | OFF | 0 (not valid) |
| OFF | OFF | OFF | ON | 1 (default) |
| OFF | OFF | ON | OFF | 2 |
| OFF | OFF | ON | ON | 3 |
| OFF | ON | OFF | OFF | 4 |
| OFF | ON | OFF | ON | 5 |
| OFF | ON | ON | OFF | 6 |
| OFF | ON | ON | ON | 7 |

Note: The "loop back" RS232 DIP switch (RS232 DIP switch 1) should be ON for each unit in the chain.

Note: Pin 4 on the RS232 DIP switch is not used.

In order to connect multiple switches (up to 7) with RS232 connections to the same CPU, an NTI Matrix-Y-1 cable must be used. Connect the Matrix-Y-1 cable (sold separately) between the RJ45-to-DB9 serial adapter (supplied) and the CPU as shown in Figure 16.




Figure 16- RS232 connection with Matrix-Y-1 cable

Wiring Schematic of Matrix-Y-1 cable




Figure 17- Pinout of Matrix-Y-1 cable

Command Protocol

RS232 commands supported by the unit are defined below. All command strings should be terminated with a <CR> (carriage return). When a command is sent, the entire string is echoed back along with a response from the addressed unit as shown in the command definitions. All characters in the command string should be upper case, and all numbers below 10 should have a leading 0 (ex: 1 = 01). As command strings are sent, the inner character delay cannot exceed 500 milliseconds.




Figure 18- RS232 Communication Illustrated

Note: To use this command protocol, the user is required to write a program that will send an entire command string all at once, not character by character. Programs that send one character at a time (such as HyperTerminal) cannot be used to control the UNIMUX. Alternatively, the user may use the NTI Switch Control Program or SerTest to control the UNIMUX via RS232 (see page 18).

Legend: (All numbers must be two digits)

- SW : Switch (01-7) (Unit Address)
- OP : Output (User) Port (01)
- BR : Baud Rate (12 =1200, 24=2400, 48=4800, 96=9600 baud)
- IP : Input (CPU) Port (01-MAXINPUTS)
- <CR> : Carriage Return (Hex 0xD)

Note: For units with one output (user) port, use 01 for the output selection.

Command Definitions

| Command String | Good Response | Description |
|----------------|-------------------------------|---|
| CS SW,IP,OP | *<CR> | Connect Output (User) Port To specific Input (CPU) Port |
| RO SW,OP | *<CR>IP<CR> | Read Connection For Output (User) Port to Input (CPU) Port |
| CB 00,BR | None | Change Baud Rate For All Switches (BR=12 (1200), 24 (2400), 48 (4800), 96 (9600) baud)- see "Note" below |
| RS SW | *<CR> | Internal Reset |
| RU SW | *<CR>IP,OP<CR> | Read Unit Size |
| SS SW,00 | *<CR> | Disable Autostatus feature (see below) |
| SS SW,01 | *<CR> | Enable Autostatus feature (see below) |
| GO SW,OP | *<CR>go SW,OP:IP<CR> | Read connection of a Output (User) Port to Input (CPU) Port (different response format than RO command) |
| GM SW,00 | *<CR>go OP,IP (all ports)<CR> | Read connection matrix of all Output (User) ports |

If the first field is not a known command (as listed above) or SW field is different from the unit address programmed at the DIP switch (page 15), the command will be ignored. If the SW field corresponds to the unit address, but if the syntax is wrong after this field, the switch will answer with a bad response ?<CR>.

Syntax example:

cs 01,05,01<CR> (insert the space and commas as shown)
 which means "At the switch with unit address 01, connect CPU port 05 to user port 01"

The switch will answer with:

*<CR>

The HEX code representation of example above is:

| Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Byte 8 | Byte 9 |
|---------------|---------------|-----------------|------------------------------|------------------------------|---------------|------------------------------|------------------------------|---------------|
| 'C' (0x43) | 'S' (0x53) | Space (0x20) | Switch – 1st digit (0x30) | Switch – 2nd digit (0x31) | ',' (0x2C) | Output – 1st digit (0x30) | Output – 2nd digit (0x35) | ',' (0x2C) |

| Byte 10 | Byte 11 | Byte 12 |
|----------------------------|----------------------------|----------------|
| Input –1st digit (0x30) | Input –2nd digit (0x31) | <CR> (0x0D) |

Note: a change in the baud rate using RS232 will only be effective until the UNIMUX is power- cycled. The DIP switch positions (page 10) will determine the set baud rate each time the UNIMUX is powered ON.

Response:

| Byte 1 | Byte 2 |
|------------|-------------|
| '*' (0x2A) | <CR> (0x0D) |

Autostatus

When Autostatus is enabled, any output (user) -to-input (CPU) connection change in the UNIMUX will cause an Autostatus message to be sent via RS232 to the administrator. The format of the message would be "pc SW,OP:IP<CR>"

Example of an Autostatus message:

pc 01,01:04<CR>

which means "At the switch with unit address 01, the output (User) (01) has changed connection to input (CPU) port 04."

Note: An Autostatus message to the administrator will be delayed by any RS232 traffic being received by the switch from the administrator.

By default, Autostatus is disabled and must be manually enabled.

NTI Switch Control Program For Windows 9X, NT, 2000, XP, And Vista

The NTI Switch Control Program is an easy and powerful graphical program that controls NTI switches through an RS232 interface. The NTI Switch Control Program can be downloaded from <http://www.networktechinc.com/srvsw-usb-dvi.html>.

To install the NTI Switch Control Program after downloading

1. Locate the **Setup.exe** in the directory the program was downloaded to and double-click on it
2. Follow the instructions on the screen

Note: *In order to use the NTI Switch Control Program to control the UNIMUX, the UNIMUX RS232 port must be set at a baud rate of 9600 bps (see page 14).*

The NTI Switch Control Program performs best on monitors set to a screen resolution of at least 800 X 600. Instruction for using the NTI Switch Control Program is available by opening "MSCP Help" in the "NTI" program group once the program has been installed and is open on the screen.

To open "MSCP Help" from the Windows desktop

1. Click on **START**
2. Click on **PROGRAMS**
3. Click on **NTI**
4. Click on **MSCP Help**

SerTest- RS232 Interface Test Program

This software allows a user to test the functions of an NTI server switch, matrix switch or Multi-user/Multi-platform/Single-user switch RS232 interface. The SerTest program is automatically loaded when installing the NTI Switch Control Program as described above. The SerTest program, located in the NTI program group, generates a main menu with the 4 selections described below:

Main Options

- Switch Operations - send commands to the unit.
- Ethernet Operations - set Ethernet connection variables (not applicable to this model)
- Setup Options - set COM port, baud rate, and unit address
- About SerTest - display the program version

If Matrix Operations is selected, the following menu is displayed:

SWITCH OPERATIONS

- 1) Reset Unit
 - send a reset command to the switch
 - the current unit address is displayed in parentheses
- 2) Reset All Units
 - send an internal reset command to all switches
- 3) Connect Output/User to an Input/CPU
 - connect an output to an input
- 4) Connect All Outputs/Users to an Input/CPU (not applicable to this model)
 - connect all outputs to an input
- 5) Connect Audio Output/User to an Input/CPU (not applicable to this model)
 - connect an output to an input
- 6) Connect All Audio Outputs/Users to an Input/CPU (not applicable to this model)
 - connect all outputs to an input
- 7) Change Mute Status for Audio Output/User (not applicable to this model)
 - mute or un-mute the Audio port output

- 8) Change Volume for Audio Output/User (not applicable to this model)
 - change Audio port output volume
- 9) Read Connection for Output/User
 - read what input is connected to the specified output
- a) Read Connection for Audio Output/User (not applicable to this model)
 - read what input is connected to the specified output
- b) Read Mute Status and Volume for Audio Output/User (not applicable to this model)
 - read the volume and the mute status of the specified output
- c) Read Unit Size
 - read the switch size (number of inputs and outputs)
- d) Read Unit Version/Revision String (not supported by this model)
 - read a string containing the switch version, type, and size
- e) Save I/O Connections into Unit Memory (not applicable to this model)
 - save the connections into switch memory bank
- f) Restore I/O Connections from Unit Memory (not applicable to this model)
 - restore the connections from switch memory bank
- g) Save All Units I/O Connections into Units Memory (not applicable to this model)
 - save the connections into switch memory bank, command for all switches
- h) Restore All Units I/O Connections from Units Memory (not applicable to this model)
 - restore the connections from switch memory bank, command for all switches
- i) Change All Units Baud Rate (9600/COM1)
 - change RS-232 Baud rate of all switches
 - the current baud rate and serial port are displayed in parentheses

Note: a change in the baud rate using SERTEST will only be effective until the UNIMUX is power-cycled. The DIP switch positions (page 14) will determine the set baud rate each time the UNIMUX is powered ON.

ETHERNET OPERATIONS (not applicable to this model)

SETUP OPTIONS

- 1) select Com port current: (COM1:)
 - select PC serial port
 - the current PC serial port is displayed in parentheses
- 2) select Baud rate current: (9600)
 - select PC serial port baud rate
 - the current baud rate is displayed in parentheses

Note: a change in the baud rate using SERTEST will only be effective until the UNIMUX is power-cycled. The DIP switch positions (page 14) will determine the set baud rate each time the UNIMUX is powered ON.

- 3) set unit Address current: (1)
 - select the unit address of the switch to be connected to by this program
 - the current address is displayed in parentheses

For any selection that requires user input, the user is prompted. When commands are sent to the UNIMUX, the command string and UNIMUX responses are echoed to the screen. All commands generated by the program are formatted according to the information provided in sections above. If any transmission problems are detected, an error message is displayed.

Press <Esc> or <Enter> to back out to the main menu and press again to exit.

DISPLAY FUNCTIONS

An NTI RACKMUX with a 17" monitor supports resolutions up to SXGA (1280x1024) with a refresh rate at between 55 and 76Hz. The quality of the image on the LCD monitor is adjustable using an On Screen Display (OSD) menu using the control buttons on the RACKMUX.

Standard Controls

The RACKMUX has 5 standard control buttons and a power LED. The 5 standard control buttons operate as follows:

- The **Power** button turns the RACKMUX LCD and backlight ON and OFF as desired.
- The **Power LED** located immediately below the Power button is a dual color LED. It will illuminate with a green color when the RACKMUX is powered ON and working properly. It will illuminate with a red color if the RACKMUX is powered ON but there is no input signal detected.
- The **Menu** button is used to bring up the OSD menu where the various settings of the LCD display can be adjusted. Once the OSD screen is displayed, the Menu button is used to make selections within the menus. See "OSD Control Menu" (below) for more on LCD display settings.
- The **Up and Down Arrow** buttons are used to navigate through the menus. Move the cursor up or down as desired to highlight an item for selection. Once an item is highlighted, pressing the Menu button will select it.




Figure 19- OSD Controls

Note: When the OSD Menu is OFF, the Up Arrow is used to toggle between a "PC" (VGA) and "Digital" (DVI) input source.

- The **Select** button is used to make selections within the OSD menus when the OSD menu is ON. When the OSD menu is OFF, the Select button will act as an **Auto Adjust** button to keep the user from having to use the menus to adjust the quality of the image on the monitor.

Note: In order to display the OSD Menu, the RACKMUX must first be connected to a video source (see "Connect the Cables" – page 9).

Note: If the message "NO SIGNAL" appears when the monitor is powered-ON, the monitor may be set for a "PC" (VGA) input source. Press the Up Arrow button on the monitor to toggle the monitor input source setting to "Digital" (DVI).

OSD Control Menu

The OSD (On Screen Display) Menu enables the user to select the desired characteristics of the LCD display. To activate the OSD Menu, press the Menu button (above). To turn the Menu back OFF, either select "EXIT" from the main menu or just wait 10-60 seconds and it will automatically be cleared from the screen. Any changes made before exiting the menu will be saved.

OSD Main Menu




Note: In order to display the OSD Menu, the RACKMUX must first be connected to a video source (see "Connect to a CPU" – page 9).

Note: If menu does not appear when the Menu button is pressed, the monitor may be set for a "PC" (VGA) input source. Press the Up Arrow button on the monitor to switch it to a "Digital" (DVI) input source.

| Selection | Purpose | Range |
|---------------------|---|---|
| Brightness/Contrast | Increase/decrease panel brightness/contrast level | 1-100 |
| Setup | <ul style="list-style-type: none"> Control OSD Image position on screen Set time OSD will stay on screen before auto shutoff Select the language of the OSD menu Select Input Source to display | <ul style="list-style-type: none"> 0-4 10 to 60 seconds English, Spanish, German, Italian, or French Digital or PC (must be set to Digital) |
| Exit | Exit from the OSD control menu | |

Brightness/Contrast Menu

Selecting the Brightness/Contrast menu will bring up a screen in which the user can adjust the brightness and contrast levels of the LCD display. Using the Up or Down arrows to navigate the menu, highlight either the BRIGHTNESS or CONTRAST sections and press the Select button to choose the option to adjust. Then use the Up or Down Arrow to adjust the setting. Select EXIT when finished to return to the Main Menu.




Setup Menu

Selecting the Setup menu will bring up a screen in which the user can adjust


- OSD POSITION-the position of the OSD menus on the LCD display (positions 0-4)
- OSD TIME-the length of time the user can be idle before the OSD menu automatically exits (adjustable from 10 to 60 seconds)
- LANGUAGE-the language that the OSD menus will be presented in
- INPUT SOURCE- the type of signal that is coming from the CPU, either Digital (DVI) or PC (VGA)

NOTE: As used on this RACKMUX, the INPUT SOURCE must be set to "Digital".

With the item highlighted, (use the Up or Down arrow to move between them), press the Select button to choose the option to adjust. Then use the Up or Down Arrow to adjust the setting as needed. Select EXIT when finished to return to the Main Menu.



OSD Image can be moved to different points on the display



KEYBOARDS

The keyboard on the RACKMUX is a standard Windows SUN keyboard with 17-key numeric keypad.

Note: The “Fn” key is not an active key on this keyboard.




Figure 20- U.S. (English) SUN Keyboard with numeric keypad




Figure 21- French SUN Keyboard with numeric keypad

Keyboard Configuration

The keyboard configuration of each CPU is saved in the UNIMUX switch. For example, if the CPU attached to Port 2 had CAPS LOCK and NUM LOCK selected the last time that CPU was accessed, then they will automatically be set when that CPU is accessed again.

TROUBLESHOOTING

PROBLEM: Keyboard Errors

SOLUTION: Check cable connections on each CPU and the switch.

PROBLEM: No Video

SOLUTION: Check cable connections on each CPU and the switch. Verify that keyboard and video connect from each CPU to matching ports. After reconnecting, CPU may need to be re-booted in order to sense the monitor connection.

PROBLEM: Keyboard/ Mouse does not work

SOLUTION: UNIMUX may be in Command mode (NumLock, ScrollLock, and CapsLock LEDs are illuminated). Only Command mode commands will be recognized while in Command mode. Press <Esc> to exit Command mode.

PROBLEM: Scan or Broadcast does not work

SOLUTION: After enabling the Scan or Broadcast mode, the user must exit Command mode for Scanning or Broadcasting to begin.

PROBLEM: In Broadcast mode, the response is quite slow or some data gets lost

SOLUTION: In Broadcast mode the data can only be entered at a rate of less than 20wpm. Try slowing down the typing rate.

PROBLEM: No Video on RACKMUX LCD monitor

SOLUTION: Make sure LCD monitor is in Digital mode, not PC mode. Adjust accordingly the OSD setting on LCD monitor (See Setup Menu- page 22)

RACKMUX SPECIFICATIONS

General Specs

| | |
|-----------------------------|---|
| Case Material..... | Electro-galvanized steel black powdercoated |
| Dimensions WxDxH (in.)..... | 19x21.9x1.75 |
| Supported Rack Depths..... | Adjustable 22" -39" |
| Input Power..... | AC 110 or 220V, 50 or 60 Hz |
| Operating Temperature..... | 0-40°C |
| Storage Temperature..... | -20-60°C |
| Relative Humidity..... | 20-90%, non-condensing |
| Approvals..... | All parts comply with RoHS |

LCD – 17"

| | |
|--------------------------------|---|
| Display area..... | 337.92mm (W)x270.336 (H) (17 inch diagonal) |
| Panel Type..... | TFT Active |
| Number of Pixels | 1280 (H)x1024 (V) |
| Number of Colors..... | 16.2 Million (6 bits + FRC) |
| Pixel Pitch..... | 0.264(H)x0.264(V) |
| Color Pixel Arrangement..... | RGB Vertical Stripe |
| Brightness..... | 300cd/m ² (Nits) |
| Response Time..... | 5.5ms |
| Viewing Angle | Horizontal: 140°; Vertical: 130° (Typ.) |
| Optimum Viewing Direction..... | 6 o'clock |
| Backlight Unit..... | CCFL, 4 Tables, Edge-Light (2 Top/2 Bottom) |
| Operating Lamp Life | 40,000-50,000 hrs |
| Contrast Ratio..... | 500:1 |

Display Controller: DVI

| | |
|---------------------------------------|--|
| Connector..... | DVI-D, female |
| Video Format | VGA, SVGA, XGA, SXGA |
| Signal Input (from Video Source)..... | Digital TMDS |
| Sync Range | H: 31 ~ 80KHz, V: 55 ~ 76Hz |
| OSD Control..... | Menu, Up, Down, Select, Power (5 keys) |
| Plug and Play..... | VESA DDC 2B Ver1.3 |

OSD Control Board

| | |
|---------------------|--|
| OSD Control | 5 Keys |
| Power Key | Power ON/OFF |
| Menu Key..... | Activates Menu |
| Up, Down Keys | Navigation Control |
| Select Key..... | Select (when in Menu); Auto Adjust (not in menu) |
| LED..... | Indicates Operation Status |
| | Green = Power-ON, Video Input OK |
| | Red = Suspend / Stand-by, or Input Out of Range |

Keyboard

| | |
|---------------------------|---|
| No. Of Keys | 83 Keys (US), 84 keys (UK, German, French, Italian, Spanish)+ 14 Sun keys |
| Key Switch Type | Membrane switch |
| Keytop Style..... | Rectangular Cylindrical |
| Operating Force..... | 50gf +/- 25gf |
| Stroke | 3.0mm +/-0.5mm |
| Tactile | 20 gf typ. |
| Height | 8.5 mm |
| Operating Life | 10M operations, minimum |
| Interface | Row and column matrix |
| Key Switch Bounce..... | 10 ms, maximum |
| Supported Platforms | USB |
| CPU Connectors..... | USB Type B |

Trackball

| | |
|---------------------------------|-------------------------------------|
| Casing Material..... | ABS |
| Ball Material..... | Phenolic (metal core) |
| Ball Color | Black |
| Ball Diameter | 16mm |
| Tracking Force..... | 10 grams nominal |
| Resolution..... | 117 pulse per ball revolution |
| Mounting Angle..... | Max. 30' to horizontal plane |
| Lifetime-Ball Revolutions | >= 1 million |
| Mechanical Buttons | 3 Mechanical switches are supported |

Touchpad

| | |
|---------------------------------------|------------------------------|
| Motion Detection Method..... | Capacitance sensing |
| X/Y Position Sensing Resolution | 40 counts/mm |
| X/Y Position Reporting..... | Relative (Similar to mouse) |
| Tracking Speed..... | Up to 1016 mm/sec |
| Touch Force..... | No Contact pressure required |
| Lifetime (Plastic Overlay) | Minimum 10,000,000 strokes |
| Sample Rate | Up to 100 samples/sec |

INDEX

| | |
|-------------------------------|------------------------------------|
| addressing, 15 | Matrix-Y-1 cable, 15 |
| Autostatus, 17 | OSD Controls, 20 |
| baud rate, 14 | <i>OSD Menu-DVI</i> , 21 |
| Broadcast mode, 12 | power-up sequence, 10 |
| Command mode , 11 | Rack mounting , 4 |
| connect the cables, 9 | RS232 commands, 16 |
| country codes, 13 | RS232 Control, 14 |
| daisy-chaining, 15 | RS232 pinout, 14 |
| Display functions , 20 | Scan mode, 12 |
| Fn key, 23 | SerTest, 18 |
| front panel control, 11 | Sun sleep mode, 13 |
| keyboard control, 11 | Switch Control Program , 18 |
| Keyboard LEDs, 23 | Telco mount, 8 |
| LEDs, 23 | |

WARRANTY INFORMATION

The warranty period on this product (parts and labor) is two (2) years from the date of purchase. Please contact Network Technologies Inc at **(800) 742-8324** (800-RGB-TECH) or **(330) 562-7070** or visit our website at <http://www.networktechinc.com/return-policy.html> for information regarding repairs and/or returns. A return authorization number is required for all repairs/returns.