



METROFLOR®

MAINTENANCE FOR METROFLOR CERAMIC BEAD FINISH TILES AND PLANKS

There are some Metroflor products that are manufactured with a permanent Ceramic Bead Finish, therefore, there is NO need to apply finish after installation, or at any time. The application of Ceramic Bead will give you years of easy maintenance and lasting beauty.

The type or frequency of traffic on your Metroflor will determine the frequency of maintenance needed. The color of the floor will have some bearing on how much care may be necessary.

Regular adherence to an effective maintenance program should include:

- thorough dirt and grit regulation
- prompt removal of spills and stains
- protection of the floor surface

The most effective part of any floor maintenance program is the simplest: sweep, dust mop or vacuum DAILY, or more frequently if needed.

INITIAL MAINTENANCE UPON COMPLETION OF THE INSTALLATION:

1. Sweep or vacuum thoroughly and remove any adhesive residue from surface with Metroflor Black Scuff/Adhesive Remover. Mineral Spirits can be used.
2. Do not wash floor for at least 48 hours after installation. Lightly damp mop with a very diluted solution of Metroflor Cleaner. Remove any scuffs and excessive soil by careful scrubbing. Certain types of rubber heel marks may be removed by rubbing with a cloth dampened with Metroflor Black Scuff/Adhesive Remover.
3. All traffic and furniture should stay off the floor for at least 24 hours to allow the adhesive to dry. Do not wash any installation for 48 hours.
4. In order to prevent indentations and scratches, provide glass, plastic or other non-staining cups with flat under surfaces not less than 2" in width for the legs of heavy furniture or appliance. Equip swiveled-type office chairs and other rolling furniture with broad surface non-staining casters at least 2" in diameter. Remove small diameter buttons from the legs of straight chairs and replace with metal glides that have bearing surfaces not less than 1" in diameter. Avoid the use of stiletto heels.
5. Protect your floor against burns. Burns from the glowing end of a cigarette, matches, or other extremely hot items can damage Metroflor floors.
6. Do not flood floor, subject to frequent standing water, or use in high moisture areas.
7. Avoid exposure to direct sunlight for prolonged periods. During peak sunlight hours, the use of drapes or blinds is recommended. Prolonged direct sunlight can result in discoloration and excessive temperatures may cause tile expansion.

ROUTINE COMMERCIAL MAINTENANCE:

1. Metroflor has excellent durability and a history of performing well in heavy commercial installations, provided a sound maintenance program is followed. Light daily sweeping, dust mopping or vacuuming will prevent dirt and grit particles from being ground into the surface of the tile. Non-rubber, non-staining walk off mats should be used to control the amount of dirt and grit reaching the floor. The mats should be as wide as the doorway and thick enough to trap dirt and should be cleaned on a regular basis. Frequent light mopping will prevent the floor from becoming heavily soiled and will remove most spills and stains. The amount and type of traffic will dictate the frequency of washing. Wash the floor by damp mopping with Metroflor Neutral Cleaner diluted with warm water.
2. If the floor receives hard use and becomes extremely dirty, as in heavily commercial installations, an occasional scrubbing may be necessary. This can be accomplished by using a low speed buffer with a red scrubbing-type (polyester or nylon) pad. Spray the floor with diluted Metroflor Neutral Cleaner and work the solution over the floor using the buffer and the scrubbing pad. Once this is accomplished, remove the dirty residue by damp mopping with clear water or with a wet vacuum.

STAIN REMOVAL

To remove stubborn spots or stains from Metroflor Ceramic Bead Finish tiles/planks, always begin with mild cleaners, such as Metroflor Neutral Cleaner or Metroflor Black Scuff/Adhesive Remover. If this fails to remove stain, use Mineral Spirits. Do not use harsh solvents, such as Acetone, or lacquer thinner, as these type products can permanently soften and damage the surface.

For extreme staining, (paints, permanent markers, dyes) try applying fingernail polish remover containing Acetone (not straight Acetone) applied to soft cloth and rubbing. Any damage resulting from use of pure solvents IS NOT covered by the warranty. Always test stronger cleaning agents on sample pieces or in unnoticeable areas first before attempting on affected areas.

SCUFFING AND SCRATCHING:

Although Metroflor Ceramic Bead Finish is very resistant to scuffing and scratching, surface damage can occur with hard enough use, or if floor is improperly maintained. If damage occurs, try hand buffing the spot with 0000 steel wool, using a solution of Metroflor Black Scuff/Adhesive Remover. If damage is deep, try using 000 steel wool.

For additional questions regarding maintenance, please contact us toll free at 866-687-6357 or visit our web site

www.metroflorusa.com