



GENERAL CARE AND MAINTENANCE COMMERCIAL SHEET VINYL

PREVENTION

The single greatest cause of damage to any flooring or floor finish is abrasion from dirt and grit. Wherever possible, use walk off mats at entrances and doorways, and vacuum mats often.

- Ensure you use non-staining mats on the floor. Rubber-backed and latex-backed mats may stain or damage the surface.
- Use non-staining floor protectors under heavy furniture and equipment.
- Chairs should have clean, smooth, non-staining floor protectors. Ensure there are no nicks or burrs on the protectors. Felt protectors must be cleaned regularly to ensure there is no grit build-up.
- When moving heavy furniture and equipment, use strips of plywood or Masonite to roll or slide the furniture or equipment.

GENERAL CARE & MAINTENANCE

Use standard maintenance industry safety practices and precautions whenever performing maintenance procedures.

Every application and every building can present its own unique set of problems which may require variations in the maintenance procedures. Choose the maintenance option that meets your area of application and maintenance equipment. The following are general guidelines that will cover the majority of applications. If you feel your situation is not covered by these guidelines, please contact Adore Floors technical services for advice before beginning your maintenance procedures.

The key to successful maintenance of all flooring types is the removal of dirt and soil. Mopping with a sponge or string mop alone removes very little soil, but rather it dissolves the dirt and spreads it out evenly across the floor creating a dull, dirty film.

Adore recommends the use of micro-fiber mops and pads for dust mopping and scrubbing. Using an automatic scrubber or wet vacuum is the preferred way to remove soiled water and rinse water.

Do not use brown or black pads or stiff-bristled brushes.

INITIAL MAINTENANCE

Note: For glued down products do not begin initial maintenance for a minimum of 72 hours after installation is complete. This is to assure the adhesive has had sufficient time to dry and cure.

- Remove all surface soil, dirt, sand and grit by vacuuming or dust mopping.
- DO NOT STRIP THE FLOOR
- Scrub the floor with a neutral pH detergent such as; Hilway Direct "Neutral Cleaner".
- Scrub the floor with rotary scrubber with a red scrubbing pad or automatic scrubber with red scrubbing pads.
- Pick up solution with a wet vacuum, rinse with clean water, allow to dry.

Note: Adore LVT does not require a floor finish to be applied, however, a floor finish may be desirable to aid in daily maintenance, stain resistance, resistance to abrasion and maintain gloss level. Essentially, a floor finish is a sacrificial wear layer. If you choose not to apply a finish than the spray buffing system should be utilized as needed. Over time floors will begin to lose their luster and require an application of polish.

If a floor finish is desired:

- Choose a Matte, Satin or Gloss shine.
- Apply 2-3 thin coats of high quality floor finish such as Hilway Direct 'Matte' or 'Satin' or 'Gloss' floor finish
- Apply with a clean finish applicator. Allow proper drying time between each coat.

Note: The higher the gloss level the more apparent will be subfloor imperfections, scratches, stains etc, and the more costly it will be to maintain a high gloss. In healthcare applications a high gloss can also have a negative effect on elderly patients. Multiple coats of high gloss may give your natural looking flooring a 'plastic' appearance. Adore Floors recommends the use of Matte or Satin shines.

DAILY MAINTENANCE

Vacuum or dust mop with a micro-fiber mop to remove all surface soil, sand and grit. Damp mop to remove surface soil using a micro-fiber mop and neutral pH cleaner such as Hilway Direct 'Neutral Cleaner'.

As Needed

Option 1 – Spray Buff System

Spray Clean/Buffer using a rotary buffing machine (175-350 rpm) with a red pad and a spray buff solution such as Diversey Snap-back.

Option 2 – Wet Scrubbing

• Scrub or mop with neutral pH detergent such as Hilway Direct 'Neutral Cleaner' or equivalent.

• Apply cleaning solution with a mop and bucket (do not flood the floor, use as little water as possible) and scrub using a rotary scrubber with scrubbing pad or use automatic scrubber with scrubbing pad.

• Pick up solution with a wet vac.

• Rinse with clean water. Scrub and Recoat (as needed if floor finish has been applied)

• Vacuum or dust mop to remove loose soil and debris.

• Using a rotary scrubber or automatic scrubber do a heavy scrub with a red scrubbing pad and a double strength of neutral pH detergent such as Hilway Direct 'Neutral Cleaner'.

• Pick up solution with a wet vacuum.

• Rinse with clean water and allow to thoroughly dry.

• Apply 2-3 thin coats of floor finish such as Hilway Direct 'Matte' or 'Satin' or 'Gloss' floor finish or equivalent.

• Apply with a clean finish applicator

• Allow proper drying time between each coat

OPERATING ROOMS

The frequent use of disinfectants in operating rooms will make the use of a floor finish impractical.

DO NOT USE PHENOLIC DISINFECTANTS ON ADORE FLOORS

Automatic Scrubbers are the most efficient, safe, cost-effective, ergonomic way to maintain your resilient flooring. Machines are available from small compact "walk behind" to large 'ride on' machines.

CAUTION: Phenolic type disinfectants are very caustic and may cause adverse effects on the physical properties of the floor covering, including leaving a slippery residue which may cause a hazardous condition. If phenolics are used, after each application, thoroughly rinse the surface with clean water and wet vac up the solution.

Always contact Adore technical services for advice BEFORE beginning your maintenance procedures.

PLEASE VISIT HILLWAY DIRECT AT:

<http://www.1877floorguy.com/adflma.html>

FOR PREFERRED CARE PRODUCTS INCLUDING FINISH, DETERGENTS, FLOOR PROTECTORS, EQUIPMENT AND MORE.