

Reach Barrier Attic Ladder Kit Assembly Instructions



1



Fold the sides of the box up and fold the ends in as shown below:

2



3

Fold the ends of the Box up and over the ends and insert the tabs into the slots in the box as shown below:



4

When finished folding your Attic Ladder Box, cover it with the Reach Barrier Insulation Wrap – The finished Kit will look like this:

