



Bristol Assembly Instructions

- 1) Push one caster into each hole in the bottom of the base. When partially inserted there will be some resistance before the caster "snaps" into position.
- 2) Insert the pneumatic cylinder into the hole in the center of the base, with the "clip" end downward. Both the base and the cylinder are tapered to ensure a tight fit.
- 3) Remove the bolt from the metal bracket underneath the seat. Insert the back upright into the slot in the seat mechanism under the seat. Thread the bolt into the metal bracket and tighten firmly to secure backrest.
- 4) Lift the chair assembly on top of the pneumatic cylinder, inserting the cylinder into the hole in the seat mechanism. Press down firmly. Weight or applied pressure will "pressure seal" these components together.