

FEEL THE HEAT!

RacePace Spare Tire Carrier

Part # **01-1011 / 1012** RZR XP900 2 Seat Models Black / Red
Part # **01-1902** RZR XP900 4 Seat Models Black

Congratulations on your purchase of the RacePace or RockSolid Spare Tire Carrier. Flats are not fun, and these UTV's don't come with a spare; don't get stuck in a bad spot carry a spare and get out every time. Be sure to check out the full line of DragonFire Accessories for your Polaris vehicle at your local authorized dealer or online at <http://www.DragonFireRacing.com>

Will only work with DragonFire BackBones and Bumpers



- Read and understand these instructions before installing product
- Installation may scratch BackBone powdercoat
- Do not use as anchor point for pulling
- Do not use product if there are any signs of damage

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

Tools Required
5/32" Allen
Wrench

Step 1: Place vehicle on a flat and level surface. Place gear selector in "Park" and remove keys from the ignition.

Step 2: Disassemble the two cage clamps and remove outside halves. Set pieces and hardware aside, they will be re-used.

Step 3: Set spare tire carrier within the BackBone's attached to the bumper. Ensure inside cage clamps are sitting flush against BackBone tubes (A&B). Secure by re-installing outside cage clamp halves and supplied hardware using a 5/32" Allen wrench. Figure 1

Step 4: This completes installation. Time to ride and enjoy!

ProTip: Periodically check all hardware and re-tighten if needed.

For further assistance please contact us at customerservice@dragonfireracing.com or 1-800-708-9803.

