

# Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041  
606-845-7439

**Instructions for Installation and Care of**  
**Bush Hog Trail Hand**  
**TH4400 4x4 & TH4200 4x2**  
**Soft Door Rear Window Combo**  
**BH-4400-DRW01**

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before opening and installing the Hush Hog Trail Hand Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. If installed outside and in the cold weather, warming the adhesive Velcro strips inside just before installation is recommended.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	10 each	5" long
“ “	1 each	26" long
“ “	2 each	15" long
“ “	2 each	8" long
“ “	6 each	6" long
“ “	2 each	12" long
Snap Studs	7 each	
Cab Enclosure	1 each	
4. Before installing the soft door rear window combo, you must first remove the hard windshield and top. The enclosure installs under these items and must be installed first.
5. Begin by installing the 26" Velcro strip as well as the two 15" adhesive strips around the top of the roll cage. First place the 26" strip along the rear bar that runs side to side across the top, this strip should be placed facing the front of the Trail Hand. Next place the two 15" strips on the top bars running front to back, these should be set towards the inside of the cab slightly towards the top at an angle.
6. Now get an assistant and attach the enclosure to these points. It may be necessary to make adjustments to get the enclosure centered and in proper position.
7. Now work your way around the enclosure placing adhesive Velcro strips on the roll cage to match the appropriate tabs.

8. Up the front of the cab you will see 3 strips of double-sided Velcro sewn along the edge. At these spots you will take the 6” adhesive Velcro strips and wrap them around the roll bar and then wrap the double-sided strip around the adhesive strip to provide a very secure hold.
9. If placement of tabs interferes with the placement of your windshield brackets you may simply cut the Velcro tabs sewn into the cab to fit around the brackets. Be sure to melt the cut ends of the Velcro tab with a lighter to avoid unraveling.
10. Mark the desired locations for the stud snaps on the fenders. Then install the stud snaps to the Trail Hand using only a #2 Phillips screwdriver.
11. Now replace the windshield and top and you are ready to go.
12. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2” in diameter to assure that the door will not stick out very far while stowed.

#### Cleaning and Storage Recommendations:

1. Before removing the Over Armour Offroad Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Over Armour Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if extra hook and loop sets are needed, they can also be ordered.

# Return Policy

## Over Armour Offroad

2515 Bypass Rd, Flemingsburg, KY 41041

Phone: 606-845-7439

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

**All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 20% restocking fee will apply.**

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

# **Warranty**

## **Over Armour Offroad**

**2515 Bypass Rd, Flemingsburg, KY 41041**  
**Phone: 606-845-7439**

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Darren Royse  
Owner/Operator

[www.overarmouroffroad.com](http://www.overarmouroffroad.com)