

# Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041  
606-845-7439

**Instructions for Installation and Care of**  
**Bush Hog Trail Hand**  
**TH4400 4x4 & TH4200 4x2**  
**Full Cab Enclosure with Polycarbonate Windshield**  
**BH-4400-FC03**

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before opening and installing the Trail Hand Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. It will help to unhook the hood and Raise the Bed prior to installing the cab enclosure
4. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	4 each	6" long
“ “	2 each	8" long
“ “	1 each	54" long
“ “	2 each	12" long
Snap Studs	7 each (1 extra)	
Cab Enclosure	1 each	
5. You will need to install the soft portion of the cab first before installing the windshield. Start by placing the cab over the top of the roll cage and pulling it down and centering it before you start placing the adhesive Velcro strips onto the roll cage.
6. Start attaching the cab from the front, making sure that the cab fits as flush as possible with the front fender and attaching the Velcro strip running up the front of the doors to the front of the roll cage.
7. Next raise the bed and place the two 12" adhesive Velcro strip across the bottom rear of the cab, align with Velcro on rear of cab. Now pull down on the rear of the cab enclosure and affix to the Velcro.
8. Now zip the doors up and make sure that the cab is centered correctly, you may have to detach the front and rear Velcro to adjust and center everything.
9. Now you're ready to begin installation of the Polycarbonate Windshield. Put it together following the instructions provided with the windshield. Then place it on the cab, putting the top of the windshield under the cab along the top. Then slide the clamps under the cab where they need to be and bolt together.

10. The next step can go one of two ways, if you were provided with a second Polycarbonate brace with your windshield then you need to cut holes in the top of the cab where the four holes are long the top of the windshield. Then sandwich the cab between the windshield and the Polycarbonate brace with the brace being on the outside and the bend in the brace being above the bolts. The second method is if you were supplied with no brace and Velcro across the top of the cab you need to place the adhesive Velcro strip across the top of the windshield where the top of the cab meets up with it and put the two pieces together.
11. Now all that is left is to mark the positions of the three snaps on the front of the doors and screw in the snaps studs into the Trail Hand. The Bottom of the Doors will hold in place with the Magnets that are sewn into the doors. The rear portion will wrap around and magnets will hold to the frame of the UTV.

#### Cleaning and Storage Recommendations:

1. Before removing the Over Armour Offroad Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Over Armour Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.



# Return Policy

## Over Armour Offroad

2515 Bypass Rd, Flemingsburg, KY 41041

Phone: 606-845-7439

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly as it was originally packaged from the factory to get a full refund for the product!

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

**All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 20% restocking fee will apply.**

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

# **Warranty**

## **Over Armour Offroad**

**2515 Bypass Rd, Flemingsburg, KY 41041**  
**Phone: 606-845-7439**

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Darren Royse  
Owner/Operator

[www.overarmouroffroad.com](http://www.overarmouroffroad.com)