

Hard Coated Full Windshield for Yamaha Wolverine
P/N: 12931
Fits: 2016 Wolverine, R-SPEC, and R-SPEC EPS
Installation Instructions

Includes:

1. (1) Hard Coated Windshield (12931-01)
2. (1) Top Stiffener (12931-03)

Hardware Kit:

1. (2) Lower Edge Brackets (12931-02)
2. (6) Rubber Fast Straps (11651)
3. (6) Plastic Rivets
4. (1) Logo Sticker

Installation:

1. Bolt the (4) lower Rubber Fast Straps to (4) slots in the windshield. Do not tighten yet.
2. Attach the metal stiffener to the top of the windshield using the (2) remaining Fast Straps and (3) Plastic Rivets. The stiffener goes between the top (2) Fast Straps and the windshield. Do not tighten yet.
3. Mount the windshield to the cage.
4. Mark the holes for the lower brackets to be drilled.
5. Drill (2) 5/16" diameter holes in the hood to mount the lower edge brackets.
6. Attach the lower edge brackets to the hood with (2) Plastic Rivets (NOTE: you will have one extra Plastic Rivet, this is just in case you need it).
7. Once again, mount the windshield to the cage and tighten all your bolts.

