



2515 Bypass Rd  
Flemingsburg, KY 41041  
(606) 845-7439

**Instructions for Installation and Care of**  
**Bob Cat 2200 HUV4421**  
**Soft Door Rear Window Combo**

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

Be sure to read these instructions thoroughly before opening and installing the Husqvarna Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. The temperature affects the adhesive Velcro, if conditions prevent installing in warmer weather it helps to store the adhesive Velcro at room temp. Prior to installation.

Carefully open the carton and remove the rolled up enclosure on a large flat surface that is clean and free of dirt. You will need to remove your windshield and hard top prior to installing the Soft Door Rear Window Combo. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	1 each	48" long
“ “ “	2 each	10" long
“ “ “	4 each	8" long
“ “ “	4 each	16" long
“ “ “	8 each	3" long
Snap Studs	9 each (1 extra)	
Cab Enclosure	1 each	

1. Loosely drape the cab enclosure over the roll cage and zip the doors closed to get the unit centered and in the right place. It will make it easier to install if you attach the Velcro along the top of the doors and across the top of the rear window to hold the enclosure up while you install the remaining Velcro pieces.
2. Now mark the correct positions for the adhesive Velcro that will match up with the Velcro tabs that are sewn down the front of the cab. These will end up under the windshield and you will need to cut the tab to fit around your windshield clamps. Be sure to melt the cut ends if the Velcro tabs with a lighter to prevent fraying.
3. You will also see two double-sided Velcro strips sewn on each side of the front. To attach these you will need to use the supplied 6" Velcro strips and wrap them around the bar where the double-sided Velcro strips are. The photos below help to show how this is done.



4. Now move to the rear of the cab and you will see that a strip of Velcro is sewn across the back and should be lined up with the bar running behind the seats. Take the 45" adhesive Velcro strip and adhere it to this bar, trying to center it as much as possible.
5. Now open the doors and you will see a 10" Velcro tab sewn into the back seam of the cab. Place the corresponding adhesive Velcro strip here and you should now be finished with installing all of the Velcro.
6. Now that all that should be left is installation of the snaps along the bottom of the doors. Just pull the door down and mark where the snap is going to hit the unit and then screw the snap studs in and you should be finished. Please Enjoy



#### Cleaning and Storage Recommendations:

1. Before removing the Over Armour Offroad Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Over Armour Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

## Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

**All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.**

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

# Warranty

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Over Armour Offroad  
[www.overarmouroffroad.com](http://www.overarmouroffroad.com)