

# Over Armour Offroad

2515 Bypass Road Flemingsburg, KY 41041  
606-845-7439

## Instructions for Installation and Care of John Deere Gator HPX-XUV Windshield/Top Combo

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before opening and installing the John Deere Gator Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.


3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	2 each	5" long
“ “	2 each	10" long
“ “	2 each	8" long
“ “	1 each	14" long
“ “	2 each	6" long
Cab Enclosure	1 each	

4. Loosely drape the Cab Enclosure over the Gator roll cage. Note the correct position for the 14" Velcro Hook strip on the underside of the front brush guard. **Clean the area with Isopropyl alcohol**, let dry and apply the Velcro hook strip. Then attach the Cab to the strip on the brush guard.



5. Working your way to the rear of the roll cage carefully fit the Cab into position. The two double-sided Velcro strips wrap around the bar after you have wrapped it with the adhesive hook strips. Note: you may need to unfasten the front nosepiece to adjust the distance and attach the rear panel first then return to the front and pull the nosepiece tight and reattach it to the brush guard. Please refer to photos below:



6. Now note the positions of the three Velcro tabs on both sides of the windshield and attach the correct size adhesive Velcro strips the roll cage as shown in the photo below. After attaching the strips pull the windshield tight side to side by attaching the Velcro tabs to the adhesive strips creating a tight wrinkle free surface to the windshield.



#### Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.