

Over Armour Offroad

2515 Bypass Road Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Kawasaki Mule 3000/3010 Soft Door Rear Window Combo KAW-3010-DRW01

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before unrolling and installing the 3010 Soft Door Rear Window Combo. The installation is best done when the temperature is 65 degrees F. or warmer. This is to help the adhesive Velcro to stick better to the roll cage. If you must install outside in the cold it will help to warm the Velcro at room temperature first.
2. Carefully unroll the Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.

3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	18 each	3" long
“ “	2 each	5" long
“ “	2 each	7" long
“ “	2 each	10" long
“ “	2 each	14" long
“ “	1each	36" long
Snap studs	9 each	(1 extra)
Cab Enclosure	1 each	

4. Begin installation by placing two 10" and two 13" adhesive Velcro tabs across the back and bars running front to back to hang the cab from. The two 10" tabs should be installed across the top tube in the rear facing the front of the mule. The two 13" strips are to be installed along the bars running front to back, these should be centered on the bar and facing towards the inside of the cab. The picture below shows how it should look.



5. Now work your way down the rear of the door, adhering the appropriate Velcro strips to match up with the tabs sewn to the doors. Make sure that the straps with Velcro ends that hold the doors are run between the roll bar and the rear cage.
6. Now work your way down the front of the door, placing adhesive Velcro strips to match up with the tabs sewn to the doors. The front tabs have been made so that if one of them happens to line up with where your windshield straps to the roll bars you can just not use it. Fold it back under the door and it will be out of the way.
7. Mark the desired locations for the stud snaps on the front fenders. You will use 4 per side. Then install the stud snaps to the Mule using only a #2 Phillips screwdriver. **Caution: Do not use a drill as damage to the Mules gas tank can occur!**
8. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2" in diameter to assure that the door will not stick out very far while stowed.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Designs Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag (I recommend a Flannel or Micro Fiber Cloth) or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.



Finished Installation

Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

Warranty

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.