

Over Armour Offroad

2515 Bypass Road Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of 3010 Full Cab Enclosure fits Lexan Windshield KAW-3010-FC05

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before unrolling and installing the 3010 Full Cab Enclosure. The installation is best done when the temperature is 65 degrees F. or warmer. This is because of the adhesive Velcro strips adhere best when warm. If installation must be done in colder weather, keep the adhesive strips indoors until ready to install.
2. Carefully unroll the Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	2 each	5" long
“ “	2 each	7" long
“ “	1 each	36" long
“ “	1 each	53" long
Snap studs	9 each (1 extra)	
Cab Enclosure	1 each	
4. Loosely drape the Cab Enclosure over the Mule roll cage. Begin in the rear of the cab and place the 36" adhesive Velcro strip on the bar running behind the seat back centered. Pull the rear window down and attach the Velcro along the bottom of the window here.
5. Now move to the front of the cab and pull down so the top of the cab fits snugly to the top of the roll cage. Working down the front of the doors, place the two 6" and one 9" adhesive Velcro tabs on the roll cage to match up with the tabs sewn to the cab enclosure.
6. Next place one 9" and one 4" adhesive Velcro strip on the roll cage down the back lower portion of the doors to match up with the Velcro tabs sewn to the cab enclosure.
7. Mark the desired locations for the stud snaps on the front fenders. You will use 4 per side. Then install the stud snaps to the Mule using only a #2 Phillips screwdriver. **Caution: Do not use a drill as damage to the Mules gas tank can occur!**

8. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2” in diameter to assure that the door will not stick out very far while stowed.
9. Now that the cab enclosure is in place it is time to install the windshield. Follow the instructions included with the windshield to assemble it and then place it on the mule by sliding it up and under the front visor and marking the position for the 53” adhesive Velcro strip across the top of the windshield. Pull the windshield back off and place the adhesive Velcro on the windshield and replace it on the mule and attach the clamps around the roll cage by sliding them under the cab and around the bars at the appropriate positions.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Designs Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag (I recommend a Flannel or Micro Fiber Cloth) or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

Warranty

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.