

Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Kawasaki 3010 TRANS Mule Rear Window

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before unrolling and installing the Rear Window. The installation is best done when the temperature is 65 degrees F. or warmer. This is to help the Velcro adhere to the Roll cage. If installation must be done outside in cold weather it helps to warm the Velcro strips prior to installing.
2. Carefully unroll the Rear Window on a large flat surface that is clean and free of dirt or other materials.
3. Check over the parts included in the carton with the parts list shown below:
1" Adhesive Velcro Hook strips: 2 each ----- 18" long

2" Adhesive Velcro Hook strips: 2 each -----45" long

Rear Window 1 each
4. First remove the Rear gate from the Trans and Lay it down on a table or on the ground. Clean the top and bottom of the gate where the Velcro is going to be attached and down the sides. The Rear Window will be installing on the side that faces the front of the Trans
5. Now install the two 45" adhesive Velcro strips across the top and bottom of the gate and lay the Rear Window down and attach the Velcro together. Now attach the two 18" Velcro strips down the sides to match up with the tabs sewn to the sides of the window. Now attach the tabs on the window to the Velcro on the gate and you are finished. Enjoy

