

Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of
RTV 900 Full Cab Enclosure
Fits Lexan Windshield
KU-RTV900-FC05

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before opening and installing the RTV 900 Full Cab Enclosure. The installation is best done when the temperature is 60 degrees F. or warmer.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material.
3. Check over the parts included in the carton with the parts list shown below:

Soft Enclosure

Velcro Hook strips:	8 each	3” long
“ “	2 each	10” long
“ “	2 each	14” long
“ “	1 each	50” long
Snap studs	20 each	(1 extra)
Cab Enclosure	1 each	

4. Loosely drape the Cab Enclosure over the RTV roll cage.
5. Working your way to the rear of the roll cage, carefully fit the Cab into position. Be sure to pull the lower edge of the rear panel down between the rear of the roll cage and the front of the dump bed. Apply the 2-14” adhesive hook strips behind the plastic piece sticking out and then fold the loop tabs under and onto the hook strips. .
6. Center the Cab left to right on the roll cage and zip the doors closed.
7. Next, Get someone to help you and pull down on both sides of the front to mark where to place the appropriate adhesive Velcro strips. Starting at the top first place the 8” strip followed by the 6” strip and then using another 6” strip wrap it around the tubing where the double-sided Velcro strip is sewn to the cab. **Be sure to clean area thoroughly with alcohol before attaching Velcro strips.**

8. Attach cab to all adhesive strip installed in step #7 and move on to installing the windshield.
9. Mark the desired locations for the stud snaps on the fenders and side panels. Then install the stud snaps to the RTV using only a #2 phillips screwdriver. **Caution: Do not use a drill as damage to the RTV's gas tank can occur!**
10. Lastly, Place a 10" adhesive Velcro strip along the side of the RTV900 above the front snaps where it matches up.
11. Now place the 50" adhesive strip across the top of your windshield to match up with the Velcro sewn to the front edge of the cab enclosure.
12. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2" in diameter to assure that the door will not stick out very far while stowed.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Designs Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.