

# Mammoth Designs

5842 Morehead Rd. Flemingsburg, KY 41041  
606-845-2227

## Instructions for Installation and Care of Kawasaki Teryx Windshield Top Combo

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before unrolling and installing the Mammoth Designs Cab Enclosure. The installation is best done when the temperature is 65 degrees F. or warmer. This is to provide the adhesive Velcro strips with their maximum power. If unable to install in warmer weather, warm adhesive strips indoors until ready to install.
2. Carefully unroll the Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab. Next Open the hood compartment and raise the bed. This will allow access to front and rear to install the necessary Velcro pieces.

3. Check over the parts included in the carton with the parts list shown below:

Self Adhesive Velcro Hook strips:	4 each	15" long
“ “	2 each	10" long
“ “	2 each	6" long
“ “	2 each	8" long
“ “	1 each	29" long Loop
Cab Enclosure	1 each	

4. Loosely drape the Cab Enclosure over the Teryx roll cage. Note the correct position for the 29" Velcro Loop and two 8" Hook strips along the bottom of the Windshield. **Clean the area with Isopropyl alcohol** let dry and apply the Velcro hook strip.
5. Working your way to the rear of the roll cage carefully fit the Cab into position. Pull down in the corner to approximate the position for the 6" Velcro strip and wrap it around the roll cage. Now pull down on the corner and wrap adhesive Velcro with the double-sided strip sewn to top. As shown in the photos below.



6. Take note of the position of the two 10” and two 15” Loop Tabs that are on both sides of the windshield. Apply the corresponding Velcro hook strips to these locations. Making sure to clean the area first.
7. Next place the two remaining 15” strips along the sides of the top to pull the top tight.

#### Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge (I recommend a flannel or Micro Fiber Cloths) using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.