

Over Armour Offroad

2515 Bypass Rd., Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Mule Kubota RTV400 Mini Cab Enclosure

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before opening and installing the RTV400 Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. This is to help the adhesive Velcro stick to the roll cage. If installation must be done outside in cold weather you must keep the Velcro warm until ready to install. You may also want to have a hair dryer or similar device to warm the roll cage as well.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	8 each	5" long
“ “	2 each	6" long
Cab Enclosure	1 each	
4. Loosely drape the Cab Enclosure over the RTV400 roll cage. Take the straps connected to the front nose and wrap them around the winch mount and run the strap through the ladder lock. Do not tighten these down yet, that will be the final step. **See Photo Below**



5. Working your way to the rear of the roll cage, pull the rear window down to determine the correct positions to place the 8" and 5" adhesive Velcro strips around the roll bars. The bottom edge of the rear window has magnets sewn in and should hold to the rear wall just below the bent lip.

6. Note the position and install four 5” adhesive Velcro strips on the left side of the roll cage for the front window. Be certain to clean the surfaces before applying the adhesive hook strips! First, apply all three strips on one side of the roll cage and attach the unit. Next note the placement and install the four 5” adhesive Velcro strips on the right side of the roll cage for the front window. Pull the window tightly toward the right side to minimize waviness or wrinkles in the front window and attach.
7. Finally pull the nose straps tight and make sure that the rear of the cab is pulled tight as well, you may need to take them off and pull a little harder to insure a tight fit. If you have any questions please call, we are always here to help.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

