

# POLARIS 2015+ RZR 900 TRAIL DOOR LOWERS AND HINGE KIT BY AXIOM SIDE BY SIDE

## PARTS LIST

ITEM	QTY	DESCRIPTION
1	1 EA	DOOR LOWER, L & R
2	1 EA	FILLER PANEL. L & R
3	4	NUT PLATE
4	4	1/4-20 X 5/8 LG SCREW
5	4	FLAT WASHER



## TOOLS REQUIRED

PHILLIPS SCREWDRIVER  
TORX BIT #T-25  
TORX BIT #T-40

## INSTALLATION INSTRUCTIONS

1. Remove six screws (T-25) from stock plastic door panel and remove the door panel.
2. Install door lower as shown in photo 1. Use two screws and flat washers and two nutplates. Hang lower door from stock door frame as shown. Position nutplates as shown. Do not tighten screws yet. Allow door lower to hang freely.
3. Re-install stock plastic door panel. Be sure tab at rear of door lower is on the outside of door panel.
4. Apply upward pressure to door lower to get it positioned properly and as tight as possible against door panel. Tighten both screws.
6. Install Hinge Kit. (optional but recommended)

Note: In some cases it may be necessary to adjust door position at factory hinges. Do so by loosening three screws (Torx T-40) make adjustment as required and re-tighten screws.

7. Install filler panels. Remove two screws (Torx T-40) from rear body panel and attach filler panel with same screws. Re-check all screws for tightness. Installation is complete.



PHOTO 1



AXIOM

S I D E X S I D E

AXIOMSIDEBYSIDE.COM

DOC NO. 15RZR900-HD1-SET-INST