

Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Yamaha Rhino Soft Rear Window YA-RHINO-RW01

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before opening and installing the Yamaha Rhino Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. If installed outside and in the cold weather, warming the adhesive Velcro strips inside just before installation is recommended.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	6 each	3" long
“ “	2 each	9" long
“ “	2 each	10" long
“ “	1 each	40" long
Cab Enclosure	1 each	
4. First place the 40" strip along the rear bar that runs side to side across the top, this strip should be placed facing the front of the Rhino.
5. Take the Rear Window and hang it from the top making sure it is centered properly.
6. Take the two 9" adhesive strips and place them on the plastic firewall at the bottom of the rear window. Make sure to match them up with the Velcro sewn along the bottom of the rear window.
7. Down the sides you will see three double sided strips and on 10" tab sewn to the edges. At each of the double-sided strips you will use a 3" adhesive strip placed on the inside of the roll cage to hold the strips in place when wrapped around the frame.
8. Where the tab in place the 10" adhesive strip on the roll cage to match up with the tab.
9. This completes the installation of your Rear Window.

Cleaning and Storage Recommendations:

1. Before removing the Over Armour Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Over Armour that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.