

Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of
Yamaha Rhino
Soft Door Kit
YA-RHINO-SDK01
FULL DOORS

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

1. Be sure to read these instructions thoroughly before opening and installing the Yamaha Rhino Door Kit. The installation is best done when the temperature is 70 degrees F. or warmer. If installed outside and in the cold weather, warming the adhesive Velcro strips inside just before installation is recommended.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	26 each	3" long
“ “	6 each	5" long
“ “	2 each	10" long
“ “	2 each	12" long
“ “	2 each	16" long
“ “	2 each	20" long
Soft Doors	2 each	
4. To install the door, start at the top and attach the adhesive Velcro to the roll cage to match up with the Velcro tabs sewn to the doors. Now work your way down the rear of the door and do the same thing. Where you see a double-sided Velcro strip sewn perpendicular to the edge of the door you will wrap the roll cage with one of the 6" adhesive strips and then wrap the double-sided strip around that.
5. The front of the door has a long 30" Velcro tab sewn to the edge. This is made to be able to cut to fit around the hardware for your windshield. Be sure to melt the edges of the tabs with a lighter after cutting it to seal it and prevent fraying.
6. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2" in diameter to assure that the door will not stick out very far while stowed.

Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. **Folding will cause damage to the windows!!!** Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Mammoth Designs that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.