



INSTALLATION INSTRUCTIONS

WIRING DIAGRAM (DO NOT WIRE POWER AND GROUND OPPOSITE)

RED= 12 VOLT SWITCHED POWER

BROWN=HORN

BLACK= CHASSIS GROUND

BLACK=GROUND FOR HORN



REAR HARNESS WIRING (FOR UNIVERSAL FITMENT)

GREEN = LEFT

WHITE=RIGHT

BLACK= BRAKE INPUT FROM CAR

RED= 12 VOLT FOR LICENSE PLATE LIGHT

(MUST GROUND BLACK WIRE FROM LICENSE PLATE LIGHT FOR LIGHT TO WORK)



LICENSE PLATE MOUNT EXAMPLE



HEADLIGHT MOUNT EXAMPLE



WARNING DO NOT BEND FLEXIBLE STRIPS OPPOSITE OF NATURAL CURVE



USE STAINLESS HARDWARE INCLUDED FOR LICENSE PLATE MOUNTING

FOR REFERENCE WE HAVE IDENTIFIED THESE WIRE COLORS AT THE REAR TAIL LIGHTS OF THE FOLLOWING VEHICLES

CAN AM WIRE COLORS (REAR HARNESS)

WHITE/ORANGE = BRAKE CIRCUIT

BLACK= GROUND

PURPLE= IGNITION 12 VOLT POSITIVE

POLARIS WIRE COLORS (REAR HARNESS)

RED= IGNITION 12 VOLT POSITIVE

BROWN = GROUND

ORANGE =BRAKE (LEFT TURN)

ORANGE/BLACK= BRAKE (RIGHT TURN)