


Floral Bracket MB-451

This decorative bracket gives elegance and support to your mailbox. It is crafted of durable cast aluminum and is available in nine finishes.

11 ³/₄" deep
8 ¹/₄" high
1 ¹/₄" wide



INSTALLING YOUR MAILBOX WITH THE FLORAL BRACKET:

Bracket includes: 8 screws

Not Included: 7 ¹/₂" x 16" ³/₄" mounting board

1. Secure post in ground approximately 18" below surface level. U.S. Postal Service requires approximately 40" from ground to mailbox bottom.
2. Install bracket per illustration at left.
3. Secure mounting board to post and bracket as per illustration.
4. Place mailbox on post assembly. Position such that mounting board does not interfere with door operation.
5. Secure mailbox to board using screws provided with mailbox.