

Wrap Around Base Mailbox Post Kit SPK590

KIT INCLUDES:.

26"x10" Wrap Around Base (WRB - 1)

Stub Post Base with set screws (SPB - 180)

58" Standard Aluminum Post (P 590)

3 screws, 1 1/4"

3 cap nuts, 1/4 • 20

INSTALLING YOUR MAILBOX WITH WRAP AROUND POST KIT :

1. Secure post in ground approximately 18" below surface level.
U.S. Postal Service requires approximately 40" from ground to mailbox bottom.
2. Use Stub Post base as template to mark drill spots on bottom of paper holder. (Positioning is left to installers discretion)
3. Drill 1/4" holes at marked locations.
4. Attach Stub Post Base to paper holder per illustration at left.
5. Place SPB over secured post and tighten with set screws.
6. Place Wrap Around Base around post by disassembling and reassembling around post as per illustration at left.

