

# Custom Carbine Feed Elbow Lock Installation Instructions

- ➊ Remove HPA Bottle
- ➋ Remove Hopper
- ➌ Remove screw that secures the front of the feed elbow.
- ➍ Slide the feed elbow off the launcher.
- ➎ Use a 1/8" drift to remove the rear feed elbow pin.
- ➏ Use the drift to start the new lock pin in the rear.
- ➐ Hold the feed elbow in proper alignment to the launcher and insert the spacer while continuing to tap the pin into place through both of the launcher anchor points.

**PBPARTSDEPOT.COM**