

RA-14L Lid Kit

Installation Directions

The RA-14L Lid Kit is designed to be used on the RA-14 Basket Kit. Your Basket Kit and Lid Kit are already pre-drilled, and hardware is included.

1. Using the Sixteen $2\frac{3}{4}$ " x $\frac{1}{4}$ " screws, attach the hinges to the RA-14L.
2. Using the Eight $2\frac{1}{2}$ " x $\frac{1}{8}$ " screws, attach the lock loops to the RA-14L.
3. Now lay the Lids with the above attached parts on top of your RA-14.
4. Using the Sixteen 2 " x $\frac{1}{4}$ " screws, attach the hinges to the RA-14.
5. Using the Six $\frac{3}{4}$ " x $\frac{1}{8}$ " screws, attach the hasp to the expanded metal sides of the RA-14.
6. The hasp is counter-sunk and should be on the outside of the RA-14. Use the backing plate on the inside of the RA-14. Make sure the hasp is positioned properly to engage the lock loop.

Installation is now complete.

Screws:

16 - $2\frac{3}{4}$ " x $\frac{1}{4}$ " screws attach hinge to RA-14L

16 - 2 " x $\frac{1}{4}$ " screws attach hinge to RA-14

8 - $2\frac{1}{2}$ " x $\frac{1}{8}$ " screws attach lock loop to RA-14L

6 - $\frac{3}{4}$ " x $\frac{1}{8}$ " screws attach hasp to RA-14