

RA-17 Motorcycle Wheel Chock

Assembly & Installation

1. Place rack on trailer floor towards front of trailer with the rack opening, which accepts the motorcycle front tire facing the rear of the trailer. Placement must permit closing the trailer door behind motorcycle.
2. Using the predrilled holes in the "H" frame mark the floor. Drill $\frac{1}{4}$ " long (depending on floor thickness). Bolt "H" frame (A) to trailer floor. Use locknuts and fender washers underneath.
3. Slowly drive or push motorcycle front wheel into rack opening. The rack will act as a stop for the motorcycle and will also stabilize the motorcycle to some degree. This will allow the motorcycle to be strapped down.
4. The rack can be removed from the "H" frame (A) by unscrewing the thumb screws (B) and sliding the rack backwards and up out of the frame.

