

RA-23 Shovel Holder Kit

(Used on RA-6) Assembly and Installation

1. Bolt Bracket (B) onto trimmer rack tower (RA-6).
2. Slide shovel holder section down on pin and bolt to bracket (B) using screw hole (E).
3. Repeat steps one and two for the lower shovel holder section.
4. Section (C) can be used alone in an enclosed trailer by screwing it into the wall using the predrilled holes (E).
5. Store shovel and brooms by sliding the tool handle through both shovel holder sections.

