

# RA-14 – Basket Kit

## Assembly

1. Insert 4 screws into the holes on the four corners of D and C through each opposite hole on A and B, hand tighten.
2. Insert 8 screws into the holes on the two rims of E through each opposite hole on C and D, hand tighten.
3. Tighten the screws through C, D and A, B, then tighten the screws through E, C and D.

## Installation

1. For 6 1/2' wide open trailers (the most popular) the basket kit will rest on the side rails as is. Mark and drill the holes. Bolt the unit to the rails. The basket also comes with a kit (4 angle iron brackets) which can be bolted to the legs on either the inside or outside to fit trailers that are wider or thinner than 6 1/2'.
2. The basket also comes with a kit (four round steel pucks) which can be bolted to the legs to make the basket taller in the event some equipment will not roll under the basket.

