

SYM (Symmetrical) Dome Awning Installation Instructions

Thank you for choosing Awnings.com, a division of Eide Industries, Inc.

Careful planning and patience are the keys to a safe and successful installation. Please review all steps of these instructions before beginning the assembly and installation of the dome awning. If you are not able to perform this installation and/or do not have the appropriate equipment and tools, we recommend hiring a local handyman or contractor for assistance.

PARTS LIST

- Dome Awning Frame - Large sizes may be delivered in two split-fit pieces.
- Sunbrella Fabric Cover - One per order.
- Lace Cords - Length varies depending upon awning size.
- Mounting Z-Clips - Quantity varies depending upon awning size.
- Tek Screws - Adequate quantity provided with split-fit frames.

NECESSARY INSTALLATION TOOLS

- Drill Motor and Drill Bits
- Hex-Head Anchor Screws or Bolts
- Ladder
- Level
- Pencil or Marking Tool
- Rubber Mallet
- Socket Set with Ratchet
- Tape Measure
- Silicon Weather Sealant

GENERAL COMMENTS

- Wash your hands before handling the Sunbrella® Fabric.
- Always be careful of the Sunbrella® Fabric during installation. Drills, ratchets, screwdrivers and other items can puncture the fabric. This and other customer installation damages are not covered by the warranty.
- For maximum efficiency and ease of installation, a second person is recommended to assist in holding the frame in place while measuring, marking and fastening the awning to the wall.
- Take your time planning and installing the new awning.

***PLEASE CAREFULLY READ INSTRUCTIONS PRIOR
TO INSTALLATION.***

STEP ONE – Check Inventory

- Check inventory to ensure all parts have been delivered.
- If parts are missing, please contact Awnings.com at 562-402-8335 extension 278 or send an email to support@awnings.com. Please reference your Order Number, if possible.

STEP TWO – Identify the Construction of the Wall

- Identify the construction of the wall (i.e. stud and stucco, stud and wood siding, concrete, brick, etc.)
- If in doubt, consult with a contractor or hardware store for the best wall anchoring solutions suitable for your needs.

STEP THREE – Determine Mounting Location

- Determine precisely where the dome awning will be installed on the wall.
- For best appearances, it is recommended to center the awning over the window or door.
- Please allow enough clearance for outward opening doors and windows.

STEP FOUR - Assemble Frame

- If necessary, fasten the awning sections with the assembly Tek Screws provided.
- NOTE: Smaller awning frames will be delivered in one welded piece and no assembly is required. Larger frames will be delivered in two pieces or sections that require simple frame assembly.

STEP FIVE – Pre-Installation of the Z-Clips

- Determine where holes will be drilled on the wall for mounting the Z-Clips.
- NOTE: Using a clock as a reference, the ideal positions for mounting the Z-Clips on the awning frame are at the 9:30, 11:00, 1:00 and 2:30 positions.

STEP SIX – Mark Mounting Location

- A second person is recommended for this step.
- Hold the frame in the precise mounting location against the wall.
- With a pencil:
 - Lightly trace the inside bow of the awning.
 - Trace the exterior of the Z-Clips.
 - Mark the drill hole locations of the Z-Clips.
- After marking, temporarily remove the frame from the wall.

STEP SEVEN – Drill Holes

- Using the appropriate drill bit style and diameter, drill the anchor screw or bolt holes where Z-Clips holes were marked.
- **LOOSELY** attach the Z-Clips in position. (NOTE: The awning frame and cover will need to be centered and leveled prior to permanently fastening to the wall.)

STEP EIGHT – Attach the Fabric Cover

- With the frame removed from the wall, gently slide or feed the ¼” awning hem into the aluminum awning rail located at the mounting bow.
- After the fabric hem is fed through the rail, carefully drape the fabric cover over frame.
- Using the supplied lace cord and starting from the center, lace the fabric cover **LOOSELY** to the awning frame. (NOTE: Lace through the cover’s grommet holes around the lace bar.)
- After lacing the entire perimeter, evenly space and center the fabric cover across the dome frame.
- Once the fabric is spaced evenly, carefully tighten the lacing and make adjustments as needed.

STEP NINE – Mount Dome Awning

- A second person is recommended for this step.
- **CAREFULLY** rest the frame and cover against the wall on the loosely attached Z-Clips.
- Center and level the awning into the required position.
- Tighten the Z-Clip fasteners. (NOTE: Z-Clips are designed for snug fit and may need to be hammered into position with a rubber mallet.)
- If necessary, apply a weather silicon sealant between the wall and awning.

Thank you for purchasing a Symmetrical (SYM) Dome Awning from Awnings.com, a division of Eide Industries, Inc. If you have any questions, please call us at (562) 402-8335 ext. 278 or via email at support@awnings.com.