



## Wire Stop<sup>®</sup> Installation

1. Drill a hole completely through the trunk/branch to be cabled. Make this hole 1/16" larger than the EHS strand being used.
2. Insert the strand, leaving approximately 6" on the outside of the tree to place the Wire Stop<sup>®</sup> over.
3. Slide the outer block of the Wire Stop<sup>®</sup> onto the strand (smaller hole towards the tree).
4. Twist or turn the strand counterclockwise until you get the evenly distributed pattern in the photo. If you don't "get it" the first time, just re-twist the strand to the original shape and try again. Do not try to bend the wires into the correct pattern by hand.
5. You may also find a nut driver helpful in obtaining the correct pattern. Use one that is 1/32" smaller than the strand being opened (11/32" for 3/8" strand). Put the nut driver over the strand and turn the driver 1/4 turn to the left to obtain the proper wire pattern.
6. Insert the taper onto the center wire (small end toward tree).
7. Using heavy-duty 8" long nose pliers, bend the middle wire over 90 degrees (this is not to hold any weight, but to prevent the taper from coming loose if wind reduces tension on the system).
8. Make sure when you are finished that the wires are distributed evenly around the taper as in the photos.
9. Trim the excess ends of the outer wires using HIT Wire Cutters (available for order on our website). Leave them extending approximately 1/8" beyond the taper.
10. An optional UV-protected black vinyl finishing cap may also be installed.
11. Moving to the second branch/trunk, drill your hole and insert the remaining end of your strand through it. Trim off any unneeded excess (again, leave 6" to place the Wire Stop<sup>®</sup> over). Tension the strand using a Havens Grip (available for order on our website), come-a-long and tree protective strap (see field installation video for details). Repeat steps 3-10 above for the second Wire Stop<sup>®</sup>. Finally, release the tension on the system and inspect your work.



**NOTE:** A washer behind the Wire Stop<sup>®</sup> is not needed, but may be used for soft wood installations. **Caution** must be used to make sure the washer does not restrict the strand and internal taper in any way!

**WESTECH RIGGING SUPPLY**

Call Toll Free: 800-442-7475

Call Us or Visit Our Stores:  
Monday - Friday, 8:00am - 5:30pm Pacific



Distributed By

Visit Us Online at: [www.WestechRigging.com](http://www.WestechRigging.com)

4140 West 11th Avenue  
Eugene, Oregon 97402

2439 McGilchrist St SE  
Salem, Oregon 97302