


Cisco 8832 IP Conference Phone Powering Options

There are 2 power configurations available for your Cisco 8832 IP Conference Phone depending on how you connect the unit to your data network – Power over Ethernet connection or standard (non-PoE) Ethernet connection.

Power over Ethernet Connection

I am connecting the Cisco 8832 to my data network via Ethernet and have a Power over Ethernet switch or Power over Ethernet injector available.

You will need to add the Cisco 8832 PoE Adapter.



Standard (non-PoE) Ethernet Connection

I am connecting the Cisco 8832 to my data network via Ethernet and do not have a Power over Ethernet switch or Power over Ethernet injector available.

You will need to add the Cisco 8832 Non-PoE Ethernet Adapter.

