


Cisco 8832 IP Conference Phone Powering Options

There are 3 power configurations available for your Cisco 8832 IP Conference Phone depending on how you connect the unit to your data network – Wifi connection, Power over Ethernet connection, standard (non-Poe) Ethernet connection.

WiFi Connection

I am connecting the Cisco 8832 to my data network via Wifi.


You will need to add the Cisco 8832 Power Supply.



Power over Ethernet Connection

I am connecting the Cisco 8832 to my data network via Ethernet and have a Power over Ethernet switch or Power over Ethernet injector available.

You will need to add the Cisco 8832 PoE Injector.



Standard (non-PoE) Ethernet Connection

I am connecting the Cisco 8832 to my data network via Ethernet and do not have a Power over Ethernet switch or Power over Ethernet injector available.

You will need to add the Cisco 8832 Non-PoE Ethernet Injector.

