


INSTALL INSTRUCTIONS C-SW SWITCHES

C-SW-3 OFF/ON/ON 3 Position Switch



C-SW-1 ON/OFF 2 Position Switch

