

2 Installation Instruction for Valve V1 Spare part no.: 200 000 573

2.1 Reason for Change

The valve V1 is now equipped in series with a stronger pressure spring. This is to ensure, if leak detector is switched „OFF“ that inlet port is not vented backwards through the valve V1.

2.2 Supplied items

Valve V1: P/N 200 001 670

Pressure spring: P/N 200 001 669



2.3 Compatibility Chart

The valve V1 is used in different product groups:

PhoeniXL 300 Family	UL1000 Family	UL5000
250002	550-100; 550-101	550-500
250000; 251000; 251100	550-000; 550-001; 550-002	550-501
250001; 251001; 251101		

2.4 Installation Instruction

- 1 For the UL1000/5000 family are *no* modifications necessary. The valve V1 could be used with the equipped pressure spring.
- 2 For the PhoeniXL 300 family the build in pressure spring of valve V1 can only be used with an I/O board in combination with revision index „01“. Please check the revision index of the I/O board on the solder side. For this, please refer to Fig. 1-2.



Fig. 1-2 Position of revision index

In case that a revision index of „00“ is indicated, the build in pressure spring must be exchanged by the pressure spring 200 001 669, which is added to the spare part!