

OSD - Password

ENTER PASSWORD : |
ESC : QUIT ENTER :



ENTER NEW PASSWORD : |
ESC : QUIT ENTER : COMPLETE



RETYPE NEW PASSWORD : |
ESC : QUIT ENTER : COMPLETE



NEW PASSWORD COMPLETE
ESC : QUIT ENTER : COMPLETE

- Changing Password
- Default password "00000000"
- Choose "Change Password"
- Key-in the existing password
- Enter the New Password
- Re-Enter the New Password
- Changing Password complete
- Max. 8 digits

Console On/OFF

- ON – any user can the console
- OFF – user is not allow to use the console, unless key-in password
- Default – OFF, you need to key-in password

Escape

- PC name show in the up-left corner
- Press "Esc" key to dear the message right away of OSD menu

102 ?SYSTEM 02