

Sub-Master Cabinet (Surface Mount)



- 10 Zone 2500-10B
- 16 Zone 2500-16B
- 32 Zone 2500-32B
- 48 Zone 2500-48B
- 64 Zone 2500-64XB
- 80 Zone 2500-80XB
- 96 Zone 2500-96XB
- 112 Zone 2500-112XB
- 128 Zone 2500-128XB

Dimensions

- 2500-10B, 16B: 15.14" H x 12" W x 6.19" D
- 2500-32B, 48B, 64XB, 80XB, 96XB, 112XB, 128XB: 21.03" H x 20.3" W x 5.19" D

Sub-Master Cabinet (Flush Mount)



- 10 Zone 2500-10F
- 16 Zone 2500-16F
- 32 Zone 2500-32F
- 48 Zone 2500-48F
- 64 Zone 2500-64XF
- 80 Zone 2500-80XF
- 96 Zone 2500-96XF
- 112 Zone 2500-112XF
- 128 Zone 2500-128XF

Dimensions

- 2500-10F, 16F:
 - *Front Frame:* 16.06" H x 14" W x 3.07" D
 - *Back Box:* 15.64" H x 12" W x 3" D
- 2500-32F, 48F, 64XF, 80XF, 96XF, 112XF, 128XF:
 - *Front Frame:* 21.13" H x 25" W x 3.06" D
 - *Back Box:* 20.66" H x 23" W x 3" D

Sub-Master (Desk Mount)



- 10 Zone 2500-10D
- 16 Zone 2500-16D
- 32 Zone 2500-32D
- 48 Zone 2500-48D
- 64 Zone 2500-64XD
- 80 Zone 2500-80XD
- 96 Zone 2500-96XD
- 112 Zone 2500-112XD
- 128 Zone 2500-128XD

Sub-Master Station:

- Surface cabinet, flush cabinet, or desk mount
- Powder coated steel enclosure with twist lock closure
- Includes handset for communication to elevators
- Sub-Master Stations to Distribution Module: Single pair
- Sub-Master stations are powered from the Distribution Module (IP based units require PoE)
- Can be configured with the main Base Station and multiple Sub-Master Stations (available in desk, surface, or flush mount)
- Audible alert sounds when phones place a call until Base Station or Sub-Master Station joins conversation
- LEDs indicate which phones have initiated a call
- Rescue personnel can communicate with individual phones and outside party
- Calls wait in queue until previous call is disconnected
- ADA, ASME A17, and B44 code compliant
- 3 year warranty

Contact Us for Larger Projects

N56W24720 N. Corporate Circle • Sussex, WI 53089
800-451-1460 • www.rathcommunications.com