


Required Items for Installation:

- Stream Video Recorder (SVR) and AC power adapter (included)
- Ethernet Cable (included)
- Broadband (Cable, DSL, or Fiber Optic) Internet connection
- Internet router
- Windows or Mac computer
- Login/password for the customer's Alarm.com account



*If you experience difficulties with the camera setup process, hold down the reset button for 15 seconds to reset the SVR.

Install the SVR:

1. Use a standard Ethernet cable to connect the SVR to the router. The SVR must be connected to the same router as the cameras you will record.
2. Connect the SVR to the AC adapter and plug it into an electrical outlet.
3. From a computer on the same network as the SVR, navigate to:
www.alarm.com/addcamera.
4. Log in to the customer account and follow the on-screen instructions to add the SVR to the Alarm.com account.

Packaging contains: [1] Stream Video Recorder (SVR), [1] Power adapter, [2] white hard drive mounting brackets and screws (may be preinstalled if hard drive is included), [1] security screw wrench for opening the SVR, [2] zip ties, and [1] Ethernet cable.