



**7847i-E  
Summary of Connections**

TB1	ECP	Zone	4204	2x4204
1	—	—	—	—
2	—	—	—	—
3	12 VDC	12 VDC	12 VDC	12 VDC
4	GND	GND	GND	GND
5	ECP IN (YEL)	Z1/Z2	ECP IN	ECP IN
6	ECP OUT (GRN)	Z3	ECP OUT	ECP OUT
7	N/U	Z4	N/U	N/U
8	N/U	Z5	N/U	N/U
9	Z6	Z6	Z6	N/U
10	Z7	Z7	Z7	N/U
11	FLT OUT	FLT OUT	FLT OUT	FLT OUT

See Instructions 800-19325 2/15

**NOTES:**

- DO NOT INSTALL IN AIR-HANDLING SPACES. INTENDED FOR DRY, INDOOR USE ONLY.

VOLTAGE: 12VDC    CURRENT: 88mA PEAK

**Warning:** Radio Frequency from transmitting devices may impair intended operation of the control unit. Maintain a minimum of 30cm between transmitting devices and control unit.

**Avertissement :** Les radiofréquences émises par les dispositifs de transmission peuvent nuire au fonctionnement prévu de l'unité de commande. Veuillez allouer une distance d'au moins 30 cm entre les dispositifs de transmission et l'unité de commande.

**Honeywell**

2 Corporate Center Drive, Suite 100  
P.O. Box 9040 Melville, NY 11747  
Copyright © 2015 Honeywell International Inc.

800-20205 2/15 Rev.A



**800-20205 2/15  
Rev.A**