

How do I use a voltage meter?

1. PLUG THE BLACK (NEGATIVE PRONG) AT COM.
2. CONNECT THE RED (POSITIVE) AT VOmA.
3. SET THE METER AT V-20 FOR ANYTHING UNDER 20V. EXAMPLE/: 6V OR 12V.
4. SET THE METER AT V-200 FOR ANYTHING OVER 20V. EXAMPLE/: 24V OR 36V.
5. CONNECT THE RED AND BLACK PRONG DIRECTLY TO THE BATTERY OR THE CHARGER FOR READING
6. TESTING A **6-VOLT** BATTERY OR CHARGER, THE READING MUST BE 6-VOLTS OR ABOVE TO BE GOOD.
7. TESTING A **12-VOLT** BATTERY OR CHARGER, THE READING MUST BE 12-VOLTS OR ABOVE TO BE GOOD.
8. TESTING A **24-VOLT** BATTERY OR CHARGER, THE READING MUST BE 24-VOLTS OR ABOVE TO BE GOOD.
9. TESTING A **36-VOLTS** BATTERY OR CHARGER, THE READING MUST BE 36-VOLTS OR ABOVE TO BE GOOD.

