

RA-10B & RA-10C

Assembly

1. This product is to be used to expand a RA-10AB Lubrication Rack which is already installed in a trailer.
2. Hang the expansion Lubrication Bin (B or C) on Lubrication Rack by sliding down on pins (C) of the already installed bin.
3. Using the predrilled holes (D), screw rack to inside wall.
4. Use the additional bin(s) for oil or other misc. tools or equipment.

