

# Wiring Diagram For Proportional Amount of Smoke (Works in Forward or Reverse)

- 6V & 12V Small Scale
- 12V Large Scale

(3V Minimum Required For 6V Version  
& 6V Minimum Required For 12V Version  
For Smoke To Start)

