



METER NOT RUNNING RIGHT?



Guide for meters used with instrument transformers

The problem is:



No Reading

Try this:



- Check CT short circuiting devices. They may be open.
- Be sure the meter is getting voltage.
- Verify the correct polarity on all CT's.
- Verify at least 5% rated current on CT's.

Low Reading

- Look for 1 or more CT closed short circuiting device.
- Verify the correct polarity on all CT's.
- Be sure voltage and current to each stator is from the same phase.
- Check register reading. Both last and present.

**Present Reading lower
than last reading**

- Look for reversed polarity on CT's or PT's.
- If disk rotation is OK, verify register readings. Maybe usage has not yet caught up with last month's too high reading.

Can't find the problem?



Call Hialeah's Experts!

800-654-0821



 **HIALEAH METER**
Meters you can believe in since 1954.

Best prices. Best service. Best meters.
Call Us Today: 1.800.654.0821