

Clear Retractable Portable Sneeze Guard Shield (#portable-sneeze-guard)



RES.100.210
39.4 x 82.7 inches
(100x210 cm)

RES.120.210
47.2 x 82.7 inches
(120x210 cm)

RES.150.210
59.1 x 82.7 inches
(150x210 cm)

Cassette			X 1
Pole		RES.100.210	X 1
		RES.120.210	X 2
		RES.150.210	X 2
Screw			X 1

Step 1
Rotate Feet

Step 2
Remove the key from the side to unlock the retractable guard

Step 3
Straighten pole until all of its parts are properly connected

Step 4
Insert pole into the hole in the base. Push all the way through until it covers the black cap in the center.

Step 5
Stand on feet and pull out retractable shield

Step 6
Place the Pole into the Hook in the Top

Suggestions: You may lean the guard over so you can comfortably insert the pole into the hook/groove at the top

Step 7
Secure screen using provided screw at the base hole where indicated. Use screw driver or power tool.

Important Note: Failure to complete this step may lead to the screen retracting back to the cassette and cause possible injury.

