


Instructions for Lady Melissa

To Activate: Open case and pull battery insulator out (clear tab).

Functions: • TIME (default display after 3 seconds) • ALARM • DATE

Adjustment Keys: Open case to view keys.

- SET (on left) - advances functions to set data.
- MODE (on right) - advances data during function setting; may also press key to toggle through each function to view current setting.




Function Setting: From the Time display, pressing the SET key advances you from the default TIME display from one function to another: starting with ALARM (fig. 1 to 5) to DATE (fig. 6 & 7) to TIME (fig. 8 & 9) for setting purposes. As each component of a function flashes, you will use the MODE key to advance the setting, e.g., ALARM hour digit(s) flash so you push mode to reach the desired hour. Once the correct hour is reached, press set for minutes setting. Repeat to reach and set the A.M.(A) or P.M. (P) component.


- ALARM (AL between digits) - Figures 1 to 5:
 - The first function you reach by pressing the SET key is the Alarm. It's necessary to set the alarm sound first. While the hour and minute numerals are flashing, press the mode key to move through the alarm sound choices. There are three choices: alarm only (fig.1); alarm & chime (fig.2) or chime only (fig.3):



(Figure 1)




(Figure 2)



(Figure 3)


B. The hour and minute numerals will remain flashing. After step "A" has been chosen, set the time of the alarm next by pressing the SET key. Press the MODE key to advance the alarm hours: A for A.M. or P for P.M. Press SET to choose the minutes. Press the MODE key to advance the alarm minutes.

Hours e.g. 4 PM



(Figure 4)

Minutes e.g. 43




(Figure 5)

Press SET when finished setting the alarm time to advance to the DATE function and advance the month by using the MODE key. Press SET to advance to the day of the month, press MODE to advance to the desired date. (Figures 6 & 7).


- DATE - Figures 6 & 7:

Month e.g. February



(Figure 6)

Day e.g. 25th




(Figure 7)

Press SET when finished setting the DATE to advance to the TIME function and advance to the desired hour by using the mode key. Press SET to advance to the minutes, press MODE to advance to the desired minute. (Figures 8 & 9)


- TIME (flashing colon) - Figures 8 & 9

Hours e.g. 2 PM



(Figure 8)

Minutes e.g. 20



(Figure 9)

Press SET when finished setting the minute to display time, press MODE to start clock.

- o Notes:

- A for A.M. (1 through 12)
- P for P.M. (1 through 12)