

INTRODUCTION

Thank you for purchasing Reminder Rosie™.

Rosie uses cutting-edge voice recognition technologies and understands English right out of the box.

HELPFUL HINTS

- a) Rosie understands normal conversational English, spoken as clearly as possible, at arms length facing Rosie.
- b) Ensure no background noise is present (radio, TV, people talking, outside noise i.e. car traffic)
- c) Rosie must be awake to understand commands. Wake up (trigger) Rosie by saying "Hello Reminder Rosie", or push her down firmly. When Rosie says "Goodbye" she goes to sleep.
- d) Rosie cannot understand your commands while she is talking.
- e) Rosie will stop talking immediately (sleep) by pushing her down firmly.
- f) Reminder Rosie has a personality, like all of us, and may take a little getting used to. You may have to repeat the time, date or other commands for her to understand you, just as you would meeting a person for the first time.
- g) Rosie recommends a family member/caregiver set up Rosie for an elderly end-user.
- h) Rosie suggests to place 3 quality AAA batteries for battery back-up.
- i) Place the tent card beside Rosie for reference. The list of all the phrases Rosie understands is listed on the back of Rosie.

GETTING STARTED

Plug into an AC outlet and Rosie will begin a brief introduction (without battery back up).

SET THE TIME & DATE

- 1. Plug Rosie into an AC outlet centrally located or where the end-user spends most of their time. The Trigger indicator light must be on. (bottom right of clock display, see #3 in diagram).
- 2. Say "Hello Reminder Rosie" to wake up Rosie, or push Rosie down firmly.
- 3. Say "Set time" and follow the prompt.
- 4. Say "Hello Reminder Rosie" to wake up Rosie again.
- 5. Say "Set date" and follow the prompts. We suggest setting the date manually as this is a one-time only setting (with battery back-up), as Rosie sometimes has difficulty hearing specific dates. Please see Manual Settings - Set Date section. Otherwise wake up Rosie and try again, emphasising the first & last letter of the date or year, i.e. "FFifteenNN" or "two-thousand & FfourteenNN".

PREPARING REMINDER RECORDINGS

We suggest you write them down. Ask the end-user (and their caregivers/providers) all their important reminders & tasks with their respective time/days/dates to be announced. List all health & wellness related tasks, both re-active (meds, doctor appointments) and pro-active (exercise, post-op tasks, eat healthy, etc.). Also list any Activity of Daily Living (ADL) reminders including personal, social, household, financial, leisure, pet, birthdays, anniversaries, etc. See an example reminder list below.

You can record a maximum of 25 reminders, up to 6 seconds long each. One reminder repeated everyday at 10 AM i.e. "I love you mom. Its time to take red and one white pill" is considered as one reminder. Reminder messages can be quite detailed; in 6 seconds you can record 15-20 words. It is not necessary to record the full 6 seconds, nor to verbally say the reminder time as part of the reminder message unless you want the user to hear the time announced with the reminder message.

REMINDER LIST EXAMPLE

Reminder	Reminder Time	Daily	Weekly	Specific Date	Annually	Comments
"Mom I love you. It's time to take 2 white and 1 red pill"	8:30 AM	Yes				
"Mom, your bridge game is at 7pm tonight, good luck!"	6:00 PM		Wed			
"Hi dad it's John. Your appointment with Dr. Jones is tomorrow at 2 PM"	11:00 AM			Mar-14-15	No	2 reminders for the same event
"Dad, your doctor appointment is in one hour"	1:00 PM			Mar-15-15	No	
"It's Justin's Birthday, call him at 555-555-1212"	5:00 PM			Dec-19-14	Yes	
"Dad its time of the month to pay all your bills"	7:00 PM			July-23-15	No	

RECORDING REMINDERS AND MESSAGES

Recording and setting reminders in the presence of as many providers (family members, caregivers) as possible, including Grandchildren creates a "community of care" atmosphere. Seniors love to hear personalized and comforting messages of loved ones to help them feel a little less lonely and increase the likelihood of accomplishing the task at hand.

- 1. Say "Hello Reminder Rosie"
- 2. Say "Record reminder"
- 3. Record a reminder and follow Rosie's prompts. Record reminders extremely loudly for louder playbacks.

COMMANDS ROSIE UNDERSTANDS

Wake up Phrase	Time & Alarm Phrases	Reminder Phrases	Time & Alarm Questions
"Hello Reminder Rosie"	Set Time Set Date Set Alarm	Record Reminder Play All Reminders Today's Reminder Reminder Off	What time is it? What day is it? What is the alarm time? <u>Sleep Phrase</u> Cancel
<u>Help menus</u> Help? What can I say?	Choose Alarm Sounds Alarm Off or Snooze		

COMMANDS AND FUNCTIONS


Action	Commands Rosie Understands	Manual Option
Wake up Rosie	"Hello Reminder Rosie"	Trigger
Put Rosie to Sleep	"Cancel"	Say after "Can I help you" or after a beep sound within 4 seconds.
Turn off a Reminder	"Reminder off"	Say between reminder announcements. Reminders announce for 30 min. or until turned off.
Hear missed Reminder(s)	"Hello Reminder Rosie"	Say when reminder indicator light (#3) Flashes and missed reminder(s) will announce once only.
Turn off the alarm	"Alarm off"	Say between alarm tones.

Or push down on Rosie firmly

Voice Only		Manual Only	
Action	Command	Action	Buttons
Record a reminder	"Record Reminders"	Turn Alarm Clock On or Off	Alarm On/Off switch
Help	"Help"		
Hear all Phrases	"What can I say?"		
Ask the Time	"What time is it?"	Turn Trigger On or Off	Trigger On/Off button
Ask the Date	"What day is it?"		
Ask the Alarm Time	"What is the alarm time?"	Dim LED brightness	Dimmer Hi/Low switch
Snooze the alarm	"Snooze"	Adjust Volume	Volume Hi/Low switch

Say between alarm sounds for 9 minutes of sleep and the alarm indicator will flash. (Maximum 3 snoozes and the alarm will automatically turn off for the day).

Voice with Optional Manual Mode		
Action	Command	Manual Mode Option
Review or Erase Reminders	"Play All Reminders"	Press clock down anytime during playback to review and/or erase reminders faster than verbal mode, using buttons on the back of Rosie. UP - Play reminders from oldest to newest DOWN - Play reminders from newest to oldest ERASE - Erase currently selected reminder ERASE ALL - Erase all reminders
Hear Today's Reminders	"Today's Reminders" (Hear all reminders set for today whether acknowledged or not)	For faster playback press Rosie down during playback of only the time/day portion of each reminder to skip to the next reminder. Pressing Rosie down any other time stops playback entirely.
Set Time, Date, Alarm & Alarm Sound	"Set Time" "Set Date" "Set Alarm" "Choose Alarm Sound"	Use buttons on back of Rosie ** See instructions below



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. ALARM indicator 2. PM indicator 3. TRIGGER / MISSED REMINDER(S) indicator 4. MICROPHONE 5. ALARM ON/OFF switch 6. ERASE ALL / TRIGGER button 7. ERASE / MODE button | <ol style="list-style-type: none"> 8. UP button 9. DOWN button 10. DIMMER HI/LO switch 11. VOLUME HI/LO switch 12. BATTERY COMPARTMENT (3AAA) 13. WAKE-UP / SLEEP / REMINDER or ALARM OFF / HEAR MISSED REMINDERS / SNOOZE buttons (Press Rosie down firmly) |
|--|--|

BATTERY BACK-UP INSTALLATION: POWER OUTAGE BATTERY MODE

Insert 3 quality AAA batteries according to the polarity noted inside the compartment on the bottom of Rosie. You can place batteries before or after Rosie is plugged in and set up. All of Rosie's functions continue to work in battery mode except the LED clock display is off and the verbal trigger does not function (press Rosie down to trigger). Reminders are stored in memory even without battery back-up and can only be erased verbally or manually.

MANUAL SETTINGS


Note: Pressing the MODE button at the back of Rosie repeatedly will cause time, alarm time, year, month, date and alarm sound option digits to flash. Each mode will flash for 5 seconds only allowing you to press UP or DOWN within that mode. Once the flashing stops, normal time display appears and you must start again.

SET DATE:

1. Press MODE button 5 times repeatedly and the 2-digit year will flash 14. While the year is still flashing (within 5-seconds) press the UP button to reach the current year. If the flashing has stopped, regular time mode appears and please start again.
2. Once the year is correct, and still flashing, quickly press mode button once more (again within 5-seconds) and the month digit will flash _1_1 (MM DD). Press the UP (or DOWN) button to reach the desired month. If the flashing has stopped press the MODE button 6 times repeatedly to reach the flashing month digits.
3. Quickly again, once the month is correct, and still flashing, press mode button once more (again within 5 seconds) and the date digits will flash: 12_1 (MM DD). Press the UP (or DOWN) button to reach the desired date. If the flashing has stopped press the MODE button 7 times repeatedly to reach the flashing date digits.

SET TIME, ALARM TIME & ALARM SOUNDS

Pressing the MODE button repeatedly will cause digits to flash in the following sequence:



- | | |
|---|--|
| <p>PRESSING MODE BUTTON)</p> <p>Press Mode 1 Time + up, down</p> <p>Press Mode 2 Times + up, down</p> <p>Press Mode 3 Times + up, down</p> <p>Press Mode 4 Times + up, down</p> <p>Press Mode 5 Times + up, down</p> <p>Press Mode 6 Times + up, down</p> <p>Press Mode 7 Times + up, down</p> <p>Press Mode 8 Times + up, down</p> | <p>MODE (Red = flashing)</p> <p>Time (Hour- HH:MM)</p> <p>Time (Minutes- HH:MM)</p> <p>Alarm Time (Hours- HH:MM)</p> <p>Alarm Time (Minutes- HH:MM)</p> <p>Date (Year- YY)</p> <p>Date (Month- MM DD)</p> <p>Date (Day- MM DD)</p> <p>4 Alarm Sounds (# 1-4)</p> |
|---|--|

RE-SET

If Rosie malfunctions, re-setting usually solves any problem. Re-setting will NOT erase reminders and reminder times, but will erase the time, date and alarm times. To re-set Rosie: 1. Unplug 2. Remove at least one of the AAA batteries 3. Plug Rosie back in. You will hear the 'auto introduction'. To skip the introduction, press Rosie down 2-3 times firmly to return Rosie to sleep mode. 4. Now place 3 AAA batteries back in Rosie 5. Re-set the time, date (and alarm time and alarm sound).

MAINTENANCE

A soft cloth or a paper towel may be used to clean your clock.

SAFETY INSTRUCTIONS

The apparatus shall not be exposed to dripping or splashing or near a bathtub. The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliance (including amplifiers) that produce heat. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, or chewed by pets. To avoid the risk of electric shock, do not remove the cover of the apparatus. There are no user serviceable parts inside. Do not operate this product if the main lead is damaged. Please read the instruction manual before use and retain for future reference. During electrostatic discharge, the product may auto-reset then adjust the mode to return normal operation.

WARRANTY - 1 Year

The WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE PARTS ONLY. In no event will Life Assistant Technologies, Inc., its representatives, affiliates, associates and the like be liable for any damages, including without limitation direct or indirect, special, incidental, punitive or consequential damages, losses or expenses arising in connection with any failure of performance of Reminder Rosie.

COMPLIANCE

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to the electronics in the device by an unauthorized dealer or technician will void the warranty.

Canadian Address: 129 Rowntree Dairy Road #4, Woodbridge, ON L4L 6C9

US Address: 2601 Workman Mill Road, City of Industry, CA, USA 90601

MADE IN CHINA

Item No. 58060