



## Bella Assembly Instructions

- 1) Push one caster into each hole in the bottom of the base. When partially inserted there will be some resistance before the caster "snaps" into position.
- 2) Slide the three piece cylinder cover over the pneumatic cylinder. Ensure the largest diameter section is facing towards the bottom of the assembly.
- 3) Insert the pneumatic cylinder into the hole in the center of the base, with the "clip" end downward. Both the base and the cylinder are tapered to ensure a tight fit.
- 4) Lift the chair assembly on top of the pneumatic cylinder, inserting the cylinder into the hole in the seat mechanism. Press down firmly. Weight or applied pressure will "pressure seal" these components together.