

Instructions for Adjure Inc., 4½” Spot Lamps For installation in H-D 2006 & Later

1. Loosen bezel screw enough to remove bezel.



2. Remove the bulb from the lamp by holding the black connector and turning the lamp clockwise.



3. Remove the bulb from the connector by spreading the clips on the side and pulling. You will not be reusing the bulb.



4. In a bag included with your new Adjure Inc. lamp there are spade terminals and insulators. Cut the terminals off of both wires on your new lamp and replace them with the male spade terminals in the bag.



MALE SPADE CONNECTORS

5. Pull the paper covering off of the rubber gasket (included) and stick it onto the backside of the new lamp.

Note: you only need to do this on the Diamond Cut lamps.



6. Place the locator ring on the bucket.



7. Push the black wire terminal of your new lamp into the black wire side of the connector and the white wire into the side of the connector with the black striped gray wire. Then fill connector with silicon to waterproof.

8. Place the lamp onto the locator ring making sure the Adjure logo is bottom dead center and push the bezel over the lamp and onto the bucket.



9. Repeat the above for the second lamp and you are ready to ride.

If you have any problems with any of our products at any time, please call us on our toll free number 888-966-9333 and we will be glad to help you. Ride Safe!