

Ford / Lincoln / Mercury TYPE A & D (PATS)

When replacing the Powertrain Control Module (PCM) on a vehicle equipped with PATS, a parameter reset or relearn procedure must be performed after the PCM is installed. Vehicles with a PATS module will not start unless an on-car procedure is successfully performed.

In order to get the vehicle to start, you must have at least one ignition key programmed to the replacement PCM. You can perform this procedure without going to the dealership or locksmith.



*Picture shown is for informational purposes only.
Actual product may vary depending on application.*

NOTE: This process will take approximately 45 minutes. Please be sure the vehicle battery is fully charged.

DIRECTIONS: Type A & D PATS

1. Use a transponder-chip key, turn the key to the 'ON' position; make sure the vehicle is NOT running.
2. The anti-theft light will flash for 15 minutes then it will turn off. Turn to the 'OFF' position for 1 second. Repeat this process two more times with same key for a total of 3 times (45 minutes)
3. After completing steps 1 & 2, turn the key to the 'OFF' position and wait 1 minute before starting the vehicle as normal.

