

Emergency Call Button with DSC Transmitter

ADC-EPB-BC2.1-DSC

Stationary Emergency Button 433 MHz

DSC Compatible

Specifications

Enclosure	4.75 in. x 2.25 in. (Diameter x Depth) Black, ABS plastic base with slip-resistant feet and 3 x AAA battery housing for optional audible message on button press Red, ABS plastic, spring-loaded push button
Electronic Signaling	Battery-powered filter circuit with integrated 433 MHz (crystal-controlled) DSC-compatible transmitter with 64 minute supervisory interval
Sensing Interface	Filtered, normally open (i.e. when not pressed), momentary contact switch
Battery Life	Replaceable 3x AAA battery: 2+ years

Programming

1. Use the Alarm.com AirFX “Add a Sensor” page or the panel interface to add the button to the account. Set the “New Sensor Information” as shown in the chart.
 - Please note that Zone Definition 15 should be used if the button will signal an emergency.
 - Zone definition 26 can be used if the button will not signal an emergency.
2. After the sensor is added to the system, change the sensor type to “Push Button.”
 - From the *Equipment* page of the Dealer Website click **Change** to the right of the sensor’s name.
 - Select the “Change Sensor Type” action, and update the new sensor type to “Push Button.”

Sensor ID	(Select an unused ID)
Zone Definition	15 (Emergency) or 26 (Non-Emergency)
Sensor Name	(Any)



Serial Number (ESN)

(On the bottom of the sensor)

Installation

Locate the sensor within 100 feet of the base station. Ensure that the On/Off switch on the base of the button is set to the “On” position. The sensor can be mounted using the included mounting plate and mounting hardware or simply place the sensor on a flat surface in a visible location.

Tamper

Note that the device may signal a tamper if the button is pressed within the first two seconds after the on/off switch is set to the “On” position.

Use

Press and hold the switch for one second.

