



# Rye Pale Ale

A pale ale that uses just the right amount of Rye, Munich and Honey malt to create a unique spiciness. Then we use three different hop varieties to perfectly balance the beer - and it's dry-hopped! To convert the Rye we have included "steep-to-convert" instructions so we recommend you have a few batches under your belt before trying this tasty recipe.

IBUs: 40 - 45	OG: 1.050 - 1.055	FG: 1.012 - 1.015
ABV: 5.3% - 5.8%	Difficulty: Intermediate	Color: Pale Amber

### Contents

- Ingredients
  - Grain Bag(s)
  - Priming Sugar
  - Bottle Caps
  - Brewing Procedures
- Hops may vary due to availability.

### Glossary

<u>OG</u> Original Gravity	<u>DME</u> Dried Malt Extract
<u>SG</u> Specific Gravity	<u>LME</u> Liquid Malt Extract
<u>FG</u> Final Gravity	<u>IBU</u> International Bittering Units ( <i>Tinseth</i> )
<u>CO2</u> Carbon Dioxide	<u>ABV</u> Alcohol by Volume

### Ingredients

- FERMENTABLES
- 6.6 lb. Light LME
- SPECIALTY GRAINS
- 12 oz. 2-row
- 1 lb. Flaked Rye
- 8 oz. Honey Malt
- 4 oz. Munich
- 2 oz. Vienna
- HOPS
- 1 oz. Bittering
- 1 oz. Flavoring
- 2 oz. Dry Hops
- YEAST
- 1 Sachet

## Recommended Procedures

NOTE: This recipe incorporates late malt additions to ensure the proper color for this beer style.

**BREW DAY** (DATE \_\_\_ / \_\_\_ / \_\_\_)

### 1. READ

Read all of the recommended procedures before you begin.

### 2. SANITIZE

Thoroughly clean and sanitize ALL brewing equipment and utensils that will come in contact with any ingredients, wort or beer.

### 3. STEEP GRAINS - see "Steep to Convert" insert

### 4. START BOIL

Bring your wort to a gentle, rolling boil. Add ONLY 3.3 lb. LME (one tin) to the boiling wort<sup>4</sup>. Continuously stir the extract into the wort as it returns to a gentle, rolling boil<sup>5</sup>.

### 5. ADD HOPS<sup>6</sup>

Slowly sprinkle the bittering hops into the boiling wort. Be careful not to let the wort boil over the pot. Using the provided BREW DAY SCHEDULE (right), note the time the bittering hops were added. Continue the gentle, rolling boil.

### 6. FOLLOW SCHEDULE

The BREW DAY SCHEDULE (right) will guide you through the remaining addition of ingredients until the boil is complete. Fill in the estimated times to help keep your brew on schedule.

## Recommended Brew Day Equipment

- 4 Gal. Brew Pot (or larger)
- 6.5 Gal. Fermenter
- Airlock
- Long Spoon or Paddle
- Hydrometer
- Thermometer
- No-Rinse Sanitizer
- Cleanser

## Brew Tips

<sup>1</sup>The volume of wort boiled affects hop utilization. Boiling more than 2.5 gallons will increase the IBU's and they will decrease if wort volume is less than 2.5 gallons. IBU's for this recipe are calculated for a 2.5 gallon boil.

<sup>2</sup>The grains should not be compacted inside the bag. Grains should steep loosely allowing the hot water to soak into all of the grain evenly.

<sup>3</sup>Pay careful attention not to let your steeping water exceed 170°F which leeches tannins into the wort.

<sup>4</sup>Run canisters of LME under hot water to allow the extract to pour easier.

<sup>5</sup>Pay careful attention that the extract does not accumulate and caramelize on the bottom of your brew pot.

<sup>6</sup>When consumed, hops can cause malignant hyperthermia in dogs, sometimes with fatal results.

## BREW DAY SCHEDULE

1. Add bittering hops \_\_\_\_\_ : \_\_\_\_ (time)
2. Boil 40 minutes
3. Add remaining 3.3 lb. LME \_\_\_\_\_ : \_\_\_\_ (time)
4. Boil 5 minutes
5. Add flavoring hops \_\_\_\_\_ : \_\_\_\_ (time)
6. Boil final 15 minutes
7. Terminate boil \_\_\_\_\_ : \_\_\_\_ (time)

Total Boil Time: 60 Minutes

Continue to Step #7

## Recommended Procedures (continued)

### 7. COOL WORT & TRANSFER

Cool the wort down to approximately 70°F by placing the brew pot in a sink filled with ice water<sup>7</sup>. Pour or siphon wort into a sanitized fermenter. Avoid transferring the heavy sediment (trub) from the brew pot to the fermenter.

### 8. ADD WATER

Add enough clean water (approx. 64° - 72°F) to the fermenter to bring your wort to approximately 5 gallons. Thoroughly stir the water into the wort. Be careful not to add a volume of water that will cause the wort to fall outside of the OG range specified in the BREW STATS<sup>8</sup>. Once you are satisfied your wort is at the proper volume and within the OG range, record the OG in the ABV% CALCULATOR (right).

### 9. PITCH YEAST

Sprinkle the contents of the yeast sachet over top of the entire wort surface and stir well with sanitized spoon or paddle. Firmly secure the lid onto the fermenter. Fill your airlock halfway with water and gently twist the airlock into the grommeted lid. Move fermenter to a dark, warm, temperature-stable area (approx. 64° - 72°F).

## FERMENTATION

### 10. MONITOR & RECORD

The wort will begin to ferment within 24 hours and you will notice CO<sub>2</sub> releasing (bubbling) out of the airlock. Within 4 - 6 days the bubbling will slow down until you see no more CO<sub>2</sub> being released. When fermentation is complete (no bubbles for 48 hours) take a FG reading with a sanitized hydrometer and record it in your ABV% CALCULATOR.<sup>9</sup>

## DRY HOPPING

### 11. ADD DRY HOPS

Add the loose pellet hops after you rack the beer into your secondary fermenter<sup>10</sup>. After a few days the hops will fall to the bottom of the fermenter and the beer can be carefully siphoned off on bottling day. If you do not use a secondary fermenter then add the hops to your primary after fermentation has completed and leave for 5-7 days before bottling.

## BOTTLING DAY (DATE \_\_\_/\_\_\_/\_\_\_)

### 12. READ

Read all of the recommended procedures before you begin.

### 13. SANITIZE

Thoroughly clean and sanitize ALL brewing equipment and utensils that will come in contact with any ingredients, wort or beer.

### 14. PREPARE PRIMING SUGAR

In a small saucepan dissolve priming sugar into 2 cups of boiling water for 5 minutes. Pour this mixture into a clean bottling bucket. Carefully siphon beer from the fermenter to a bottling bucket. Avoid transferring any sediment. Stir gently for about a minute.

### 15. BOTTLE

Using your siphon setup and bottling wand, fill the bottles<sup>11</sup> to within approximately one inch of the top of the bottle. Use a bottle capper to apply sanitized crown caps.

### 16. BOTTLE CONDITION

Move the bottles to a dark, warm, temperature-stable area (approx. 64° - 72°F). Over the next two weeks the bottles will naturally carbonate. Carbonation times vary depending on the temperature and beer style, so be patient if it takes a week or so longer.

CHILL & ENJOY YOUR TASTY BREW AND THANK YOU FOR CHOOSING  
BREWER'S BEST® PRODUCTS.

## Brew Tips

<sup>7</sup>To avoid bacteria growth do this as rapidly as possible. Do not add ice directly to the wort. Alternatively, you can use a brewing accessory like a Wort Chiller.

<sup>8</sup>Use a sanitized hydrometer while adding water to monitor the SG.

<sup>9</sup>Consider transferring your beer to a secondary carboy, see "Two-Stage (Secondary) Fermentation" sidebar below.

<sup>10</sup>Optionally, you can place the hops in a mesh bag attached to a string. This will allow you to easily remove the hops before siphoning the beer into your bottling bucket.

<sup>11</sup>Use standard crown bottles, preferably amber color. Make sure bottles are thoroughly clean. Use a bottle brush if necessary to remove stubborn deposits. Bottles should be sanitized prior to filling.

## Two-Stage (Secondary) Fermentation

Brewer's Best® recommends home brewers employ the practice of a two-stage fermentation. This will allow your finished beer to have more clarity and an overall better, purer flavor. All you need is a 5-gallon carboy, drilled stopper, airlock and siphon setup to transfer the beer. You will also need to monitor and record the SG with your hydrometer when the beer is in the 'primary'. When the fermentation slows (5-7 days), but before it completes, simply transfer the beer into the carboy and allow fermentation to finish in the 'secondary'. Leave the beer for about two weeks and then proceed to Bottling Day. Consult your local retailer to learn more about this technique.

(SECONDARY RACK DATE \_\_\_/\_\_\_/\_\_\_)

## Recommended Bottling Day Equipment

- 6.5 Gal. Bottling Bucket
- Siphon Setup
- Bottle Filling Wand
- 12 oz. Bottles (approx. 53)
- Brewer's Best® Crown Caps
- Bottle Brush
- Capper
- Sanitizer

## ABV% Calculator

(OG - FG) x 131.25 = ABV%

(\_\_\_\_\_\* - \_\_\_\_\_\*\*) x 131.25 = \_\_\_\_%

\*OG from Step #8

\*\*FG from Step #10



Brewer's Best is a registered trademark of the LD Carlson Co.